



Wireless N300 Range Extender
DMG-112A

QUICK INSTALLATION GUIDE

КРАТКОЕ РУКОВОДСТВО ПО УСТАНОВКЕ

GUÍA DE INSTALACIÓN RÁPIDA


GUIA DE INSTALAÇÃO RÁPIDA

快速安裝指南

PETUNJUK PEMASANGAN CEPAT



CONTENTS OF PACKAGING




WIRELESS N300 RANGE EXTENDER DMG-112A

If this item is missing from your package, please contact your reseller.

INTRODUCTION

The DMG-112A extends the wireless coverage of an existing AP (access point) or wireless router, allowing you to reach more parts of your home with wireless coverage. It can intuitively communicate with your router to ensure your wireless devices receive the best internet connection at all times throughout your home network.



PRODUCT SETUP


SETUP

SELECT YOUR METHOD

There are two methods available for setting up the DMG-112A. These are: using the D-Link One-Touch app (recommended) or Wi-Fi Protected Setup (WPS).

SET UP DMG-112A WITH THE D-LINK ONE-TOUCH APP

The DMG-112A can be configured using your smartphone. Search for the "D-Link One-Touch" in the Apple App Store or Google Play, and download the app.



Plug the DMG-112A into a 5V/1A USB power adaptor, then plug the USB power adaptor into a power outlet and wait until the blue power LED is on.

NOTE: To ensure that the DMG-112A receives adequate power, please only use a 5V/1A USB power adaptor. Computer USB output of the 5V/500mA is not up to the requirements of power equipment 5V/1A, unable to make the equipment normal use, if forced to use can damage the equipment °

PRODUCT SETUP

SETUP



Launch the "D-Link One-Touch" app on your device and select the D-Link 112A device listed under the "**Ready for Setup**" section. Follow the application's prompts to complete the setup.



Once you have completed the installation, the application will save a Wireless Profile Card on your device, displaying the DMG-112A's updated information for future reference .

NOTE: Please remember to store your Wireless Profile Card in a safe place on your device.

PRODUCT SETUP

SETUP

SET UP DMG-112A USING Wi-Fi PROTECTED SETUP (WPS)

NOTE: To connect to a wireless router or AP and extend the Wi-Fi network in your home, please make sure the source router or AP features a WPS Push Button.

Push the WPS button on the source wireless router or AP, and then push the WPS button on the DMG-112A. The middle white LED on the DMG-112A will start to flash.

Please allow up to two minutes for the configuration process to finish. Once configuration between the DMG-112A and the router is complete, the white LEDs will light up to indicate the strength of the signal between the DMG-112A and the router it is connected to. The DMG-112A is now connected successfully and ready to share the extended Wi-Fi network with your PCs and mobile devices. If the white LED does not turn on, you will need to repeat the WPS setup process.

The SSID will be the same as the router that you are extending from.

TROUBLESHOOTING

SETUP AND CONFIGURATION PROBLEMS

1. HOW DO I RESET MY DMG-112A WIRELESS N300 RANGE EXTENDER TO FACTORY DEFAULT SETTINGS?

- Ensure the product is powered on.
- Press and hold the WPS button for 6 seconds or longer until the bottom white LED begins to flash.

Note: Resetting the product to the factory default will erase the current configuration settings. The default Wi-Fi network name (SSID) is **dlink-112A-z** with no password required.

2. HOW DO I CONNECT A PC OR OTHER DEVICE TO THE DMG-112A IF I HAVE FORGOTTEN MY WI-FI NETWORK NAME (SSID) OR WI-FI PASSWORD?

- If you haven't changed the extended Wi-Fi network's settings, you can use the default Wi-Fi network name (SSID) **dlink-112A-z** with no password required.
- If you did change the network name (SSID) or Wi-Fi password and you deleted the Wi-Fi Profile Card saved on your device, you must reset the device as described in Question 1 above.

TECHNICAL SUPPORT

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Australia:

Tel: 1300-766-868

24/7 Technical Support

Web: <http://www.dlink.com.au>

E-mail: support@dlink.com.au

India:

Tel: +91-832-2856000

Toll Free 1800-233-0000

Web: www.dlink.co.in

E-Mail: helpdesk@dlink.co.in

Singapore, Thailand,

Indonesia, Malaysia,

Philippines, Vietnam:

Singapore - www.dlink.com.sg

Thailand - www.dlink.co.th

Indonesia - www.dlink.co.id

Malaysia - www.dlink.com.my

Philippines - www.dlink.com.ph

Vietnam - www.dlink.com.vn

Korea:

Tel : +82-2-2028-1810

Monday to Friday

9:00am to 6:00pm

Web : <http://d-link.co.kr>

E-mail : g2b@d-link.co.kr

New Zealand:

Tel: 0800-900-900

24/7 Technical Support

Web: <http://www.dlink.co.nz>

E-mail: support@dlink.co.nz

South Africa and Sub Sahara Region:

Tel: +27 12 661 2025

08600 DLINK

(for South Africa only)

Monday to Friday 8:30am to

9:00pm South Africa Time

Web: <http://www.d-link.co.za>

E-mail: support@d-link.co.za

D-Link Middle East - Dubai, U.A.E.

Plot No. S31102,

Jebel Ali Free Zone South,

P.O.Box 18224, Dubai,

U.A.E.

Tel: +971-4-8809022

Fax: +971-4-8809066 /

8809069

TECHNICAL SUPPORT

Technical Support:

+971-4-8809033

General Inquiries: info.me@
dlinkmea.comTech Support: support.me@
dlinkmea.com**Egypt**

1, Makram Ebeid Street -

City Lights Building

Nasrcity - Cairo, Egypt

Floor 6, office C2

Tel.: +2 02 26718375 - +2 02
26717280Technical Support: +2 02
26738470General Inquiries: info.eg@
dlinkmea.comTech Support: support.eg@
dlinkmea.com**Kingdom of Saudi Arabia**

Office # 84 ,

Al Khaleej Building (
Mujamathu Al-Khaleej)Opp. King Fahd Road, Olaya
Riyadh - Saudi Arabia

Tel: +966 1121 70008

Technical Support:

+966 1121 70009

General Inquiries: info.sa@
dlinkmea.comTech Support: support.sa@
dlinkmea.com**Pakistan**

Islamabad Office:

61-A, Jinnah Avenue, Blue
Area,Suite # 11, EBC, Saudi Pak
Tower,

Islamabad - Pakistan

Tel.: +92-51-2800397,
2800398

Fax: +92-51-2800399

Karachi Office:D-147/1, KDA Scheme # 1,
Opposite Mudassir Park,
Karsaz Road,

Karachi – Pakistan

Phone: +92-21-34548158,
34326649

Fax: +92-21-4375727

Technical Support:

+92-21-34548310, 34305069

General Inquiries: info.pk@
dlinkmea.comTech Support: support.pk@
dlinkmea.com

TECHNICAL SUPPORT

Iran

Unit 5, 5th Floor, No. 20,
17th Alley , Bokharest St. ,
Argentine Sq. ,
Tehran IRAN
Postal Code : 1513833817
Tel: +98-21-88880918,19
+98-21-88706653,54
General Inquiries: info.ir@
dlinkmea.com
Tech Support: support.ir@
dlinkmea.com

Morocco

M.I.T.C
Route de Nouaceur angle
RS et CT 1029 Bureau N°
312 ET 337
Casablanca , Maroc
Phone : +212 663 72 73 24
Email: support.na@
dlinkmea.com

Lebanon RMA center

Dbayeh/Lebanon
PO Box:901589
Tel: +961 4 54 49 71 Ext:14
Fax: +961 4 54 49 71 Ext:12
Email: taoun@dlinkmea.com

Bahrain

Technical Support: +973 1
3332904

Kuwait:

Technical Support: +965
22453939 / +965 22453949

Türkiye

Büyükdere Cad. Ferro Plaza
No:155
D: 1 K: 1 Zincirlikuyu /
İstanbul
Tel: +90 (212) 289-56-59
Email: info.tr@dlink.com.tr

ישראל

מטלון סנטר
רח' המגשימים 20
קרית מטלון, פ"ת 49348, ת"ד 7060
טל: 03-9215173
טל: 073-7962797
דוא"ל כללי: info@dlink.co.il
דוא"ל תמיכה: support@dlink.co.il

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WIRELESS NETWORK REMINDER

Wireless Network Name [SSID]

Wireless Network Password