

8. Configuration photographs

Conducted emission at mains port [Centronics I/F mode]



The photographs show maximized emission configuration.

Radiated emission [Centronics I/F mode]



The photographs show maximized emission configuration.

Conducted emission at mains port [Serial I/F mode]



The photographs show maximized emission configuration.

Radiated emission [Serial I/F mode]



The photographs show maximized emission configuration.

Conducted emission at mains port [USB I/F mode]



The photographs show maximized emission configuration.

Radiated emission [USB I/F mode]



The photographs show maximized emission configuration.

Conducted emission at mains port [LAN I/F mode]



The photographs show maximized emission configuration.

Radiated emission [LAN I/F mode]



The photographs show maximized emission configuration.