



MODEL 2206

Set switch to "Talkie" position:


- Press and hold the "Push-To-Talk" button to talk, and release it to hear.
- Press and hold the "Signal" button to release signal.

Set switch to "Torch" position:

- The torch light on.

How To Use:


- Insert 3x1.5V "AA" size batteries into the battery compartment.
- Beware of the positive and negative sign.



Caution:

- Turn power off when not play.
- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries, do not mix alkaline, standard carbon zinc or rechargeable nickel cadmium batteries.
- Non-rechargeable batteries are not to be charged.
- Exhausted batteries to be removed from the unit.
- Remove batteries when not in use for prolonged period.
- Packing with instruction to be kept for reference.

MADE IN CHINA



WARNING:
NOT SUITABLE FOR CHILDREN
UNDER 36 MONTHS DUE TO
SMALL PARTS



Patent Pending & Design Registered.



WARNING:
CHOKING HAZARD - small parts,
Not for children under 3 years.