





INVERTER



MAINBOARD

ADAPTER



signal cable
to PC

