

Driveway Patrol

Congratulation on purchasing the Driveway Patrol. Your set comes with a Chime unit and a PIR sensor which are both battery operated. You can opt to use a DC adaptor for the Chime unit. This Patrol system is simple to install and it requires no wiring.

Installing the Batteries

After you have set the switches, install the batteries.

1. The chime unit requires three C-size batteries. To install the chime unit's batteries remove the compartment cover and then install the receiver's batteries. Be sure that to observe correct polarity (+ and -) as marked inside the battery compartment.
2. The PIR sensor requires a 9V battery. To install the push button's battery, unscrew the back cover of the sensor and insert the battery. Be sure that to observe correct polarity (+ and -) as marked inside the battery compartment.

Operation

1. Set the Hi-Lo-Off switch on the side of the Chime unit to Hi or Lo.
2. Place the PIR sensor near the front gate or rear door. Any movement nearby will trigger the chime unit to sound.
3. Please ensure to place the PIR sensor at least 4 feet high to have proper function.

Specifications

Transmission Range: 400 feet (open area)
Transmission frequency: 434MHz
Receiver: 3 x 1.5V battery, not included
Transmitter: 1 x 9V battery, not included

Remark

Modifications not authorized by the manufacturer may void users authority to operate this device.

NOTE

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.