







UUT - MAGNI-CAM Interface Box, Top Cover Removed
Shows Interface PWB - Component Side




UUT MAGNI-CAM Interface PWB - Foil Side




Bottom of Camera Enclosure Showing White LEDs




Camera PWB - Component Top Side



Camera PWB - Foil/Component Bottom Side




Camera Contrast/Mode Control
& LED Interface Board - Top Side




Camera Contrast/Mode Control
& LED Interface Board - Bottom Side




Antenna & TV Terminal Label
Showing Location of Ch.3/Ch4. Switch



Battery Charger PWB - Component Side



Battery Charger PWB - Foil Side



Interface Board to Re-Chargeable Battery (No Components)



Re-Chargeable Battery Removed From Base Unit