


100g双胶纸彩色印刷，风琴折页，折叠SIZE：80x90mm



### C060



#### In the Box



Headset



USB Charging Cable




User Manual



3.5mm Audio Cable


#### Controls & Features



Labels: Boom Microphone, ANC LED, ANC Button, Volume Up Button, Power Button, Volume Down Button, Status LED, USC Charging Port, Audio In Port


#### Pairing

1. For first use, press and hold the power button for 5 seconds or more



Hold > 5 sec  
- The headset will power on and enter pairing mode (shown with blue and red flashing LEDs)

2. Choose "C060" to connect



\* Headset will automatically connect to your device after initial connection as long as Bluetooth is on.

#### Touch Controls


|                                                                                                                                      |            |
|--------------------------------------------------------------------------------------------------------------------------------------|------------|
| Single Press = ANC On/ OFF                                                                                                           | [ANC Icon] |
| Hold for 2 Seconds = Next Track<br>Single Press = Increase Volume                                                                    | [+]        |
| Hold for 5 Seconds = Bluetooth Pairing<br>Hold for 3 Seconds = On/Off<br>Single Press = Play/Pause<br>Single Press = Answer/End Call | [P]        |
| Hold for 2 Seconds = Previous Track<br>Single Press = Decrease Volume                                                                | [-]        |

#### LED Light Language

|                      |                   |                     |
|----------------------|-------------------|---------------------|
| Power On             | [Blue Light Icon] | Blue light flash x3 |
| Power Off            | [Red Light Icon]  | Red light flash x1  |
| BT Paring            | [Flash Icon]      | Flash               |
| BT Connected         | [Blue Light Icon] | Flashing every 5s   |
| Low Battery Reminder | [Red Light Icon]  | Flashing red light  |
| Charging in Progress | [Red Light Icon]  | Red light on        |
| Charging Complete    | [Red Light Icon]  | Red light off       |
| Anc On               | [Blue Light Icon] | Blue ANC light on   |
| ANC Off              | [Blue Light Icon] | Blue ANC light off  |

#### Charging

It takes 2 hours to fully charge headphones. While charging, the battery indicator light is white. It flashes blue when charging is complete.



Note: The lifetime of the battery will be significantly reduced if your headphones are left uncharged for a long period of time. We recommend that you recharge your headphone at least once a month.

#### Product Specifications

Lithium Ion Batteries:  
Model: 652035, 3.7V, 420mAh  
Battery Factory: SHENZHEN MEI NI INDUSTRIAL CO., LTD.  
Battery Factory Address: F4, NO. 28, Jinfeng Road, Yangnei Gang Village, Longgang District, Shenzhen

Use this product in an environment with a temperature between 0℃ and 45℃; otherwise, it may become damaged.

KOSS Corporation  
Model: KOSS CS340BT QZ  
Hereby declares that Bluetooth Headset, Model: KOSS CS340BT QZ is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

KOSS Corporation  
Model: KOSS CS340BT QZ  
Bluetooth Version: 5.0  
DC input: 5V=250mA  
Case Battery Capacity: 420mAh 1.6Wh  
Made in China

#### WARNING

Using earbuds at high volumes for extended periods of time may result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety.  
Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds. Earbuds may not work properly under high temperature or high humidity conditions.  
Do not use any corrosive cleaner/oil to clean the earbuds. If the earbuds come in contact with liquids, quickly wipe away. If submerged in water, do not turn the earbuds on until completely dried. Liquid submersion voids the warranty.  
Keep the earbuds and packaging out of reach of children.

##### Battery warning!

- \* Do not disassemble, strike, crush or put the battery into fire.
- \* Do not expose the battery to conductive materials, liquids, fire, or high temperatures.
- \* Do not allow metal objects to touch the two poles of the battery.
- \* Do not continue to use the battery if it has bulges, leaks, discoloration, odors.
- \* Do not use the battery after it has been submerged in water.
- \* If the battery is used improperly, it may explode or leak, causing burns and other personal injuries.
- \* If the battery leaks, it should be carefully disposed of according to the local laws and regulations concerning battery disposal.

The Directive on Waste Electrical and Electronic Equipment (WEEE), which entered into force as European law on 14/02/2014, resulted in a major change in the treatment of electrical equipment at end-of-life. The purpose of the Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal.

The WEEE logo on the product or on its box indication collection for electrical and electronic equipment consist of the crossed-out wheeled bin, as shown below.



#### FCC WARNING

This device contains license-exempt transmitter(s)/receiver(s) that This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC RF exposure statement:  
The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment.

IC STATEMENT  
This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license exempt RSS(s). Operation is subject to the following two conditions:(1) This device may not cause interference.(2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.