



Appendix A (Normative) – DFS Test Setup Photographs


1.1 EUT – DFS Test Setup (Radiated method, Primary 4x4 radio, P2P & P2MP mode) Front View



1.2 EUT – DFS Test Setup (Radiated method, Primary 4x4 radio, P2P & P2MP mode) Side View




1.3 EUT – DFS Test Setup (Radiated method, Primary 4x4 radio, Client mode: Injection at Master) Front View




1.4 EUT – DFS Test Setup (Radiated method, Primary 4x4 radio, Client mode: Injection at Master) Side View




1.5 EUT – DFS Test Setup (Radiated method, Primary 4x4 radio, Client mode: Injection at Client) Front View



1.6 EUT – DFS Test Setup (Radiated method, Primary 4x4 radio, Client mode: Injection at Client) Side View




1.7 EUT – DFS Test Setup (Radiated method, Secondary 4x4 radio, P2P & P2MP mode) Front View




1.8 EUT – DFS Test Setup (Radiated method, Secondary 4x4 radio, P2P & P2MP mode) Side View




1.9 EUT – DFS Test Setup (Radiated method, Secondary 4x4 radio, Client mode: Injection at Master) Front View



1.10 EUT – DFS Test Setup (Radiated method, Secondary 4x4 radio, Client mode: Injection at Master) Side View




1.11 EUT – DFS Test Setup (Radiated method, Secondary 4x4 radio, Client mode: Injection at Client) Front View




1.12 EUT – DFS Test Setup (Radiated method, Secondary 4x4 radio, Client mode: Injection at Client) Side View




1.13 EUT – DFS Test Setup (Radiated method, Primary 8x8 Dual radio, P2P & P2MP mode) Front View



1.14 EUT – DFS Test Setup (Radiated method, Primary 8x8 Dual radio, P2P & P2MP mode) Side View




1.15 EUT – DFS Test Setup (Radiated method, Primary 8x8 Dual radio, Client mode: Injection at Master) Front View



1.16 EUT – DFS Test Setup (Radiated method, Primary 8x8 Dual radio, Client mode: Injection at Master) Side View



1.17 EUT – DFS Test Setup (Radiated method, Primary 8x8 Dual radio, Client mode: Injection at Client) Front View



1.18 EUT – DFS Test Setup (Radiated method, Primary 8x8 Dual radio, Client mode: Injection at Client) Side View

