

Mkr 240.5MHz *-60.20dBm Tek

Ref Lvl*21.0dBm 10dB/ Atten 20dB

M-WIBS1900

-29.

59.

-59.

79.

30.0MHz to 1.000 0GHz

ResBW 100kHz VidBW 100kHz SWP 550mS

TRIG

SPAN

VidBW 100kHz

KNOB

KNOB

KEYPAD

ektroni

2784

Plot 3.8.8

Mkr 1.930 0GHz *-54.00dBm Tek

Ref Lvl*21.0dBm 10dB/ Atten 20dB

M-WIBS1900

Av#100

1.000 0GHz to 1.930 0GHz
ResBW 1MHz VidBW 7MHz SWP 20mS

TRIG SPAN

Mkr 1.930 0GHz

KNDB

KNDB

KEYPAD

Tek


2784

Mkr 1.940 14GHz *7.20dBm Tek

Ref Lvl*21.0dBm 10dB/ Atten 20dB

M-WIBS1900

AV#100



1.930 00GHz to 1.990 00GHz

ResBW 1MHz VidBW 7MHz SWP 20mS

TRIG SPAN

VidBW 7MHz


KNOB

KNOB

KEYPAD

ak on1

2784



KnOB 2

KnOB

KEYPAD

Tektronix

2784

Mkr 9 96GHz * 64 00dBm Tek

R f Lv * 0dBm 0dB/ Att n 0dB

M-WIBS1900

Av#100

10.00GHz to 20.00GHz
ResBW 1MHz VidBW 7MHz SWP 100mS

TRIG SPAN

R f Lv * 0dBm

Plot 5.96

Mkr 744.9MHz *-64.40dBm Tek

Ref 11.0dBm 10dB/ Atten 20dB

M-WBS1900

-9.

29.0

59.0

-69.

30.0MHz to 1.000 0GHz

ResBW 100kHz VidBW 100kHz SWP 550mS

TRIG SPAN

VidBW 100kHz

KNOB 2

KNOB

KEYPAD

ektron1

2784

Plot 5

Mkr 929 CHz * 53 90dBm Tek

Ref Lv *2 0dBm 0dB/ Atten 20dB

M WBS 900

Av#100


000 0GHz to 930 0GHz
ResBW MHz V dBW 7MHz SWP 20mS

TRIG SPAN

Stop 930 0GHz

Knob KEYPAD ek onl 2784

Plot 5



Tek

Mkr 1.930 00GHz

*--53.50dBm

Ref Lvl*21.0dBm

10dB/

Atten 20dB

M--WIBS1900

AV#100

930 00GHz to 990 00GHz

ResBW MHz

V dBW 7MHz

SWP 20mS

TR G

SPAN

Mkr

930 00GHz

KNDB

KNDB

KEYPAD

ektron1


2784

Plot 5 30

-9.

-59.

-69.



KNOB 2

KNOB 1

KEYPAD

Tektronix

2784

Mkr 9 92GHz * 59 60dBm Tek

Ref L V * 0dBm 0dB/ Atten 0dB

M-WIBS1900

Av#100

-9.

29.

-39.

-49,0

-59.

-69.

-89.

10.00GHz to 20.00GHz

ResBW 1MHz VidBW 7MHz SWP 100mS

TRIG

SPAN

Atten 0dB

KNOB 2

KNOB

KEYPAD

extrom

2784

Plot 55