

Inside the CCD housing is a camera and 2.4GHz transmitter. AC adaptor power cord is charge mode can't trasnmitting.