

AGES 6+
244622

FCC ID: LU9244622

CELL PHONE WALKIE TALKIES

THE
**ULTIMATE
WALKIE
TALKIE**

- OPERATION IS SIMPLE
- PUSH BUTTON AND TALK
- 4 TRANSISTORS
- MORSE CODE KEY
- ON/OFF SWITCH

A	B	C	D	E
F	G	H	I	J
K	L	M	N	O
P	Q	R	S	T
U	V	W	X	Y
Z	1	2	3	4
5	6	7	8	
9	0			



BATTERY INSTALLATION:

- OPEN THE BATTERY DOOR LOCATED IN THE BACK OF THE UNIT.
- INSTALL ONE 9-VOLT ALKALINE BATTERY INTO EACH UNIT. BE SURE TO FOLLOW THE BATTERY INDICATIONS AS SHOWN ON THE INSIDE OF THE BATTERY COMPARTMENT.
- REPLACE THE BATTERY DOOR.
- IF SOUND BECOMES DISTORTED OR WEAK, REPLACE THE BATTERY.
- REMOVE BATTERIES TO PREVENT LEAKAGE IF UNITS ARE NOT IN USE FOR LONG PERIODS OF TIME.

HOW TO OPERATE:

- TURN THE "ON / OFF" SWITCH TO "ON" POSITION. YOUR TRANSCEIVER IS NOW READY TO OPERATE.
- PRESS THE "PUSH TO TALK" BUTTON FOR TRANSMITTING.
- WHEN TRANSMITTING, SPEAK CLEARLY IN A NORMAL VOICE, HOLDING THE SET ABOUT 3" FROM YOUR MOUTH.
- RELEASE THE "PUSH TO TALK" BUTTON TO RECEIVE MESSAGE FROM THE OTHER PARTY.
- BEST TRANSMISSION AND RECEPTION ARE OBTAINED WHEN THE ANTENNA IS HELD IN A VERTICAL POSITION.
- YOU CAN TRANSMIT MORSE CODE SIGNAL BY PRESSING THE "PUSH TO TALK" BUTTON AND PRESS THE "MORSE CODE" KEY. RELEASE THE MORSE CODE KEY QUICKLY TO SEND A "." DOT, OR HOLD THE KEY LONGER TO SEND A "-" DASH.

PRECAUTIONS:

- YOUR TRANSCEIVER SET HAS BEEN FULLY ADJUSTED PRIOR TO SHIPMENT FROM THE FACTORY. BE SURE NOT TO TOUCH THE INTERNAL COMPONENTS OTHER THAN REPLACING THE BATTERY.
- WHEN THE SOUND BECOMES WEAK, IT IS TIME TO CHANGE THE BATTERY.
- AFTER USE, ALWAYS TURN "ON-OFF" SWITCH TO THE "OFF" POSITION.
- KEEP YOUR SET IN A DRY AND CLEAN PLACE.
- REMOVE THE BATTERIES WHEN WALKIE TALKIES ARE NOT IN USE.
- ALL WALKIE TALKIES ARE SUBJECT TO ELECTRONIC INTERFERENCE. IF YOU EXPERIENCE PROBLEMS WITH THIS UNIT, STAY AWAY FROM IT OR TURN OFF: CORDLESS PHONES, BABY MONITORS, INTERCOMS OR ANY OTHER "BROADCAST" DEVICES.

OPERATING PERFORMANCE MAY BE AFFECTED BY SURROUNDING STRUCTURES AND EQUIPMENT.

THE USER SHALL NOT CHANGE OR MODIFY THE EQUIPMENT. OTHERWISE IT COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.



PRINTED ON
RECYCLABLE
PAPER

MGA
ENTERTAINMENT®

TM & © 2000 MGA Entertainment, Inc.
All Rights Reserved.
16730 Schoenborn Street
North Hills, CA 91343 USA
www.mga.com
1-800-222-4685
In California, please dial
1-818-894-2525

MADE IN CHINA

AGES 6+
244622

FCC ID: LU9244622

WALKIE TALKIE WALKIE TALKIES

THE
ULTIMATE
WALKIE
TALKIE

~SUPER COMPACT SIZE
~MORSE CODE KEY
~WORKS UP TO 150
FEET

MGA
ENTERTAINMENT

USES 2 9-VOLT BATTERIES (NOT INCLUDED)