

Power Ranger logo

248354

Radio-Controlled Vehicle

Operating Instructions

INSTALLATION OF BATTERIES

Receiver

- Unscrew the battery cover
- Insert 3 X AA alkaline batteries with the positive (+) and negative (-) ends facing in the proper direction as indicated
- Replace the cover.

Transmitter

- Unscrew the battery cover
- Insert one 9V alkaline battery with the positive (+) and negative (-) ends facing in the proper direction as indicated
- Replace the cover.

SAFETY BATTERY USAGE

- Do not use rechargeable batteries;
- Non-rechargeable batteries are not to be recharged;
- Different types of batteries or new and used batteries are not to be mixed;
- Only batteries of same or equivalent type as recommended are to be used;
- Batteries are to be inserted with the correct polarity;
- Exhausted batteries are not to be short-circuited;
- The supply terminals are not to be short-circuited.
- Do not dispose of batteries in fire, batteries may explode or leak.
- Batteries should be replaced by an adult.

CAUTION:

- Not suitable for children under 3 years.
- May contain small parts.
- **Do not dispose of batteries in fire; batteries may explode or leak.**

CARING FOR YOUR DEVICE

- Your device has been fully adjusted prior to shipment from the factory. Be sure not to touch the internal components other than replacing batteries.
- After use, always turn the power to the 'OFF' position.
- Keep your set in a dry and clean place.
- In most cases, unit malfunctions occur because of weak batteries.

Time ForceVehicle (Receiver)

ON/OFF – To turn the unit on/off.

Wing Release– Press to release wings.

Time Brace Handset (Transmitter)

Antenna Lock – Press to pop out the antenna.

Forward – Press to let the vehicle goes forward.

Reverse/Turn – Press and the unit will turn reverse.

TO START

1. Transmitter - Switch the ON/OFF button to 'ON' position and pop out the antenna.
2. Receiver – Switch the ON/OFF button to 'ON' position.
3. Press the “Forward” button on the Time Brace Handset to move the Time Force Vehicle forward. Press the “Reverse/Turn” button to move the vehicle in a reverse left direction.

HELPFUL HINT

When the Time Force Vehicle fails to respond to the commands of the Time Brace Handset, it may be due to interference caused by other radio signals. Try moving to a different location, outside the range of the interference, to resume play. If the problem persists, it is time to change the batteries.

REMARK:

Modifications not authorized b the manufacturer may void users authority to operate this device.

LIMITED 90 DAY WARRANTY

MGA Entertainment warrants to the original purchaser that the product will be free from defects in material or workmanship for a period of 90 days from the date of original purchase.

This warranty does not cover damages resulting from misuse, improper or abnormal usage, negligence, leaking batteries, improper service or other causes not arising from defects in material or workmanship.

During this 90 day warranty period, the product will be either repaired or replaced (at MGA's option) at no charge to the purchaser, when returned to either the retailer with the original sales receipt (containing date of purchase) or to MGA.

The foregoing states the purchaser's sole and exclusive remedy for any breach of warranty with respect to the product.

All product returned to MGA must be shipped prepaid and insured for loss or damage to:

MGA Entertainment
Repair Department
16730 Schoenborn Street
North Hills, CA 91343-6122

Any returned product should be carefully packed in packing material sufficient to avoid damage during shipment. Please include a written description of the defect, a copy of the original sales receipt (containing date of purchase) and your printed name, address and telephone number.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific rights and you may also have other rights which vary from state to state.

This warranty is only valid within the United States and Canada.

Please keep this Instruction Sheet since it contains important information.

TM & © 2001 Saban. Power Rangers Time Force and all logos, names, and distinctive likenesses are the exclusive property of Saban Entertainment, Inc. and Saban International N.V. Fox Kids and the related logo are the exclusive property of Fox. All Rights Reserved.



TM, ® & © 2001 MGA Entertainment

All Rights Reserved

16730 Schoenborn St.

North Hills, CA 91343 USA

(800) 222-4685

(add new "Visit MGAE.com" icon)

CA (818) 894-2525

Made In China