

THE AMAZING SPIDER-MAN®

FIRE RESCUE

Item no.: 322245


Ages 3+

INTRODUCTION

Spider-Man is out to save the day but this time, instead of battling bad guys, he's riding with the Fire Department and putting out fires!

CONTENTS

- The Amazing Spider-Man Fire Rescue RC with Spider-Man™ figure (non-removable)
- Three Function Remote Control Handset



BEFORE YOU BEGIN

To power up your Spider-Man Fire Rescue RC Vehicle, install the following:


- One (1) 9V/6LR61 battery (not included) in the remote control transmitter and four (4) AA batteries for the vehicle.

NOTE: Batteries included are for in store demonstration only. Please change batteries when you take the product home before playing.

INSTALLING BATTERIES

In the Remote Control Transmitter:


1. Use a Philips screwdriver (not included) to remove the battery door screw and battery door. (See Fig. 1)



2. Insert one (1) 9V battery (not included) in the battery compartment with the positive (+) and negative (-) end facing to the proper direction as indicated inside the compartment.
3. Replace the battery door and tighten the screw.

In the Amazing Spider-Man Fire Rescue Remote Control Vehicle:

4. Slide the vehicle power switch to the OFF position. (Be sure the water tank is empty before changing the batteries)
5. Turn the unit over and, using a Philip's screwdriver (not included) to remove the battery door screw and battery door. (See Fig. 2)



6. Replace four (4) AA batteries in the battery compartment with the positive (+) and negative (-) ends facing the proper direction as indicated inside the compartment.
7. Replace the battery door and tighten the screw.

SAFETY BATTERY USAGE


1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the toy before being charged.
3. Rechargeable batteries are only to be charged under adult supervision.
4. Different types of batteries or new and used batteries are not to be mixed.
5. Only batteries of the same or equivalent type as recommended are to be used.
6. Batteries are to be inserted with the correct polarity.
7. Exhausted batteries are to be removed from the toy.
8. The supply terminals are not to be short-circuited.
9. Do not dispose the batteries in fire, batteries may leak or explode.
10. Batteries should be replaced by adult.
11. Use alkaline batteries for better performance.

QUICK START

Be the first to answer the fire alarm! With you at the controls, The Amazing Spider-Man Fire Rescue Vehicle will be on the job in a jiffy! To get rolling, first:

- Pull out and dispose of the "try-me" tab underneath the vehicle to allow all the functions of the vehicle to operate normally.
- Fill the tank on the Amazing Spider-Man Fire Rescue Vehicle with clean water and close the cap tightly. (See Fig. 3 and Fig. 4)

NOTE: Use only cold water in your Amazing Spider-Man Fire Rescue Vehicle. Any other type of liquid/hot water may cause damage to the vehicle pump.



Now use the following functions on The Amazing Spider-Man Fire Rescue Vehicle and the Three-Position Remote Control to hit the road!

VEHICLE FUNCTIONS


Slide the Vehicle ON/OFF switch to the ON position.

- **BUTTON A**
 - Press once (do not hold) and the siren lights will flash for 3 seconds.
 - Press and hold and the siren lights will flash until button is released.
- **BUTTON B**
 - Press once (do not hold) for siren sound.
 - Press and hold and the siren will sound continuously until the button is released.


NOTE: When the Vehicle ON/OFF switch is in the ON position, the headlights will remain on. After 5 minutes without play, the vehicle will automatically shut down to save battery power. Press any key on the remote or turn the vehicle switch OFF and ON again to wake the vehicle up.

REMOTE CONTROL FUNCTIONS

- **NORMAL MODE WITH SOUND**
- Press the FORWARD button – the vehicle moves forward, the engine roars and the siren lights flash. (See Fig. 5)




- Press the REVERSE button – the vehicle moves backward and steers to the left while back-up alarm sounds. (See Fig. 6)



- Press the FIRE button on the remote – the siren sounds and the vehicle will pump water. Pumping will stop when the button is released. (See Fig. 7)

NOTE: the first time the pump is used, allow few seconds before water will shoot out due to the length of the hose.



- Press a combination of the FORWARD or REVERSE button along with the FIRE button and the vehicle will pump water
 - **NORMAL MODE WITHOUT SOUND**
 - The vehicle will perform all functions above without the siren sound.
 - **OFF MODE**
 - The vehicle power will turn off and the battery supply will be disconnected.
- NOTE: The Remote Control will operate the Vehicle up to approximately 30 feet away.

Now, practice driving your Amazing Spider-Man Fire Rescue RC Vehicle so you'll be ready to rush to the next emergency and save the day!

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION

1. Empty the water tank after play.
2. Do not turn over the Amazing Spider-Man Fire Rescue RC Vehicle when there is water in the tank.
3. Check for the battery compartment of the Amazing Spider-Man Fire Rescue RC Vehicle and be sure it is dry after play.
4. Protect or cover any play surface before using.

Please keep this manual. It contains important information.



© MGA Entertainment, Inc.
16300 Roscoe Blvd.
Van Nuys, CA 91406 USA
(800) 222-4685
Printed in China



MARVEL, The Amazing Spider-Man and the distinctive likenesses thereof are trademarks of Marvel Characters, Inc. and are used with permission. Copyright © 2005 Marvel Characters, Inc. All rights reserved.
www.marvel.com
The Amazing Spider-Man Fire Rescue Radio Controlled is produced and distributed by MGA Entertainment, Inc.

The preferred method of contact for Customer Service is through our e-mail contact form at www.mgae.com



0206-0