




Ages: 4+



Item no. 330561


ADULT BATTERY INSTALLATION REQUIRED

INTRODUCTION

The Bratz Big Babyz™ are cruisin' the crib in style on their new, radio controlled, Motor-Bike! When going out to meet their best gal pals on this beauty, the dazzlin' design keeps the fashion rollin'!

CONTENTS

- 1 Bratz Big Babyz™
- 1 Bratz Big Babyz™ R/C Trike with working Headlight
- 1 Full-Function Remote Control Handset.



BEFORE YOU BEGIN

Get ready to hit the road! But first, ask an adult to help you install batteries. Here's how:

TRIKE

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover located on the underside of the bike. (see Fig. 1)
2. Install four (4) AA alkaline batteries (included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.




Fig. 1

REMOTE CONTROL

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover on the back of the Remote Control.
2. Install one (1) 9-Volt alkaline battery (included) making sure the (+) and (-) ends face the proper direction as indicated on the battery connector.
3. Replace the compartment cover and tighten the screw. (see Fig. 2)




Fig. 2

QUICK START

1. Press the ON/OFF "gas cap" switch on top of the gas tank of the cycle to turn the cycle ON. This will automatically turn on the headlight also. (Press the switch again to turn OFF the cycle and headlight.) (see Fig. 3)
2. Turn the ON/OFF switch on the Remote Control to ON. (see Fig. 4)
3. Set the cycle on a smooth flat surface away from traffic.
4. To drive forward, turn the Left RC stick forward. (see Fig. 5)
5. To drive backward, turn the Left RC stick backward. (see Fig. 5)
6. To steer right, turn the Right RC stick to the right. (see Fig. 5)
7. To steer to the left, turn the Left RC stick to the left. (see Fig. 5)




Fig. 3




Fig. 4




Fig. 5

Now that you've practiced a few moves with your Bratz Big Babyz™ R/C Trike, put pedal to the metal and tear it up!

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly authorized by the party responsible for compliance could void user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

SAFE BATTERY USAGE

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the toy before being charged.
3. Rechargeable batteries are only to be charged under adult supervision.
4. Different types of batteries or new and used batteries are not to be mixed.
5. Only batteries of the same or equivalent type as recommended are to be used.
6. Batteries are to be inserted with the correct polarity.
7. Exhausted batteries are to be removed from the toy.
8. The supply terminals are not to be short-circuited.
9. Do not dispose the batteries in fire, batteries may leak or explode.
10. Batteries should be replaced by adult.
11. Use alkaline batteries for better performance.

CAUTION

- DO NOT operate this vehicle during thunderstorms.
- DO NOT expose the vehicle or remote control to water or moisture of any kind as it may cause irreparable damage to the unit.
- Keep hair, loose clothing and other items away from rotating wheels of the unit
- DO NOT operate this vehicle on streets with cars or traffic of any kind.
- DO NOT attempt flips, wheelies or any other type of tricks as they may result in irreparable damage to the unit.
- DO NOT attempt to stand or sit on trike. Such an action could result in damage to product as well as injury to yourself.

HELPFUL HINTS

- Since your vehicle is controlled by radio frequency, it may interfere with other radio controlled devices. If this occurs, move the vehicle to another location away from the interference.
- The vehicle must remain in remote control range to operate correctly. The range depends on the surrounding area and on the strength of the battery. Obstructions such as buildings, fences, etc., between the remote control transmitter and the vehicle, reduce the range.
- If the vehicle begins to run slowly, replace the batteries with fresh alkaline batteries.

Please keep this manual as it contains important information.



0706-0

www.bratz.com
TM & © MGA Entertainment, Inc.
BRATZ™, BRATZ PETZ™, LIL' BRATZ™,
BRATZ BABYZ™, and all related logos, names,
characters, distinctive likenesses and slogans,
as well as the packaging and images appearing
thereon, are the exclusive property of MGA.
16300 Roscoe Blvd.
Van Nuys, CA 91406 USA
(800) 222-4685
Printed in China.

The preferred method of contact for
Customer Service is through our e-mail
contact form at www.mgae.com

