



Annex A – Frequency Stability


Naming Convention: Frequency (MHz) Measurement (Freq Tol) Temperature (-50, -40 -30, -20, -10, 0, 10, 20, 30, 40, 50, 60, 70, 80, 85), Voltage (Low voltage, High Voltage) Port (P1, P2)




5915 MHz FREQ TOL -10 P1



5915 MHz FREQ TOL -10 P2



5915 MHz FREQ TOL -20 P1



5915 MHz FREQ TOL -20 P2



5915 MHz FREQ TOL -30 P1



5915 MHz FREQ TOL -30 P2



5915 MHz FREQ TOL 0 P1





5915 MHz FREQ TOL 0 P2



5915 MHz FREQ TOL 10 P1





5915 MHz FREQ TOL 10 P2





5915 MHz FREQ TOL 20 P1

5915 MHz FREQ TOL 20 P2



5915 MHz FREQ TOL 30 P1

5915 MHz FREQ TOL 30 P2



5915 MHz FREQ TOL 40 P1

5915 MHz FREQ TOL 40 P2



5915 MHz FREQ TOL 50 P1



5915 MHz FREQ TOL 50 P2



5915 MHz FREQ TOL 13.2V P1



5915 MHz FREQ TOL 13.2V P2




5915 MHz FREQ TOL 10.8V P1



5915 MHz FREQ TOL 10.8V P2




5915 MHZ FREQ TOL -40 P1



5915 MHZ FREQ TOL -40 P2




5915 MHZ FREQ TOL -50 P1





5915 MHZ FREQ TOL -50 P2



5915 MHZ FREQ TOL 60 P1





5915 MHZ FREQ TOL 60 P2





5915 MHZ FREQ TOL 70 P1

5915 MHZ FREQ TOL 70 P2



5915 MHZ FREQ TOL 80 P1

5915 MHZ FREQ TOL 80 P2



5915 MHZ FREQ TOL 85 P1

5915 MHZ FREQ TOL 85 P2