


1. ID LABEL



Notes:

1. MLFB Number
2. Serial Number Barcode (size: 3.5mm x 20mm): this is the BSM's random serial number, which is linked to each module assembly components including (1) the transmitters barcode number / tic code information and (2) the Keypad ID Code Number.
3. Serial Number (human readable form) . Date Code
4. Last two digits of each transmitter's tic code.
5. Keypad ID Code Number, from the Keypad ID Code Card

