

D C B A
TRANSMIT ANTENNAS

D C B A
RECEIVE ANTENNAS

Identity
by **sirit**

READER
P/N: IDFLEX-CB

RS-232



DC POWER INPUT



RESET



WEIGAND OUTPUTS



SYNC



HOST



DISCRETE INPUTS / OUTPUTS



A0993