

EXHIBIT A

[FCC Ref. 2.1033(b)(3)]

"Installation and Operating Instructions
Furnished to the User"

Exhibit A(1)-1 - Owner's Manual

GRACO®

Family Listen 'n Talk™ Monitor

Owner's Manual • Please save for future use.

Family Listen 'n Talk™ Moniteur

Manuel d'utilisateur


Veuillez garder pour usage ultérieur.

Monitor Family Listen 'n Talk™

Manual del propietario

Por favor, conservélo para utilizarlo en el futuro.

2775



Model • Modèle • Modelo: _____ Serial No. • No. de Série • N° de Série: _____

Dear Customer,

Please fill in the model and serial numbers above from the label inside the battery compartment of your new nursery monitor.

Graco is the recognized leader in the design and manufacture of quality baby products. We believe your new Graco nursery monitor is a wise choice.

Before using your nursery monitor, please take a few minutes to read this Owner's Manual. The short time you spend reading these instructions will help you use your nursery monitor properly.

Cher client,

Veuillez inscrire ci-haut les numéros de modèle et de série que vous trouverez sur l'étiquette à l'intérieur du compartiment de la pile de votre moniteur.

Graco est le chef de file dans la conception et la fabrication de produits de qualité pour bébé. Nous croyons que le moniteur de nursery de Graco est un choix judicieux.

Avant d'utiliser votre moniteur de nursery, prenez quelques minutes pour lire le manuel d'utilisateur. Ce court instant que vous prendrez à lire les instructions vous aidera à utiliser correctement votre moniteur de nursery.

Estimado cliente,

Complete los números de modelo y de serie arriba indicados de la etiqueta dentro del compartimiento de pilas de su nuevo monitor de bebés.

Graco es el líder reconocido en el diseño y fabricación de productos infantiles de calidad. Creemos que su nuevo monitor de bebés Graco es una buena selección.

Antes de usar su nuevo monitor de bebés, tome unos minutos para leer este manual del propietario. Los pocos minutos que tome leyendo estas instrucciones le ayudarán a usar su monitor de bebés correctamente.

© 2000 Graco 904-9-00

Product Features

Caractéristiques du produit

Características del producto

A	Antenna	Antenne	Antena
B	ON/OFF/Volume	Interrupteur marche/arrêt et contrôle de volume	Encendido/Apagado/ Volumen
C	Power Light	Voyant lumineux	Luz de encendido
D	SoundLights™	SoundLights™	SoundLights™
E	AC Adapter Jack	Prise pour adaptateur CA	Enchufe adaptador VCA
F	Push to Talk Baby Button	Bouton appuyer pour parler-bébé	Botón de comunicación con el bebé
G	Channel Selector*	Sélecteur de fréquence*	Selector de canal*

*The Parent Unit and the Nursery Unit MUST be set to the same channel. If receiver detects sounds from another nursery monitor or cordless phone, set units to the other channel. If problem persists, contact Graco.

*L'unité des parents et celui de la nursery DOIVENT tous les deux être réglés à la même fréquence. Si le récepteur détecte des sons d'un autre moniteur de nursery ou de téléphones sans fil, placez les unités à une autre fréquence. Si le problème persiste, contactez Graco.

*Tanto la unidad de los padres como la unidad del bebé DEBE sintonizarse al mismo canal. Si el receptor detecta sonidos de otro monitor de bebés o un teléfono inalámbrico, sintonice ambas unidades al otro canal. Si el problema persiste, póngase en contacto con Graco.

FCC ID M6Y 001020900T and M6Y 001020900R


903-9-00

2

Nursery Unit

Unité de la nursery



Unidad del bebé



Parent's Unit

Unité des parents

Unidad de los padres



AC Adapter (2)

Adaptateur CA (2)

Adaptador VCA (2)

Questions?

In the U.S.A. or Canada, please contact our Customer Service Department with any questions you may have concerning parts, use, or maintenance. When you contact us, please have your product's model and serial numbers ready so that we may help you efficiently.



Telephone us at:
Téléphonez-nous au:
Llámenos al:
USA: 1-800-345-4109
Canada: 1-800-667-8184
Montreal: 514-344-3533

Des questions?

Aux États-Unis ou au Canada, veuillez contacter notre département du service à la clientèle avec des questions que vous pourriez avoir concernant les pièces, l'utilisation ou l'entretien. Lorsque vous nous contactez, soyez prêt à fournir les numéros de modèle et de série afin que nous puissions vous aider plus rapidement.



or visit our website,
ou visitez notre website,
o visite nuestro sitio Web,
USA: www.gracobaby.com
Canada: www.graco.net

¿Preguntas?

En los EE.UU. y Canadá, por favor contacte a nuestro Departamento de Servicio al Cliente con cualquier pregunta que pueda tener sobre las piezas, uso o mantenimiento. Cuando nos contacte, por favor tenga el número del modelo y número de serie listos para que podamos ayudarlo mejor.



or write to us at:
sinon, écrivez-nous à:
o escribanos a:

USA:

Graco Children's Products
Customer Service Department
P.O. Box 100, Main Street
Elverson, PA 19520

Canada: distributed by

Elfe

4580 Hickmore
St. Laurent, Quebec H4T 1K2



⚠ WARNING

Failure to follow these warnings and the assembly instructions could result in serious injury or death.



This device is designed only to monitor the sounds of your child. It will not alert you to your child's silent activities. This product is not designed or intended for use as a medical monitor. Always be sure that both the transmitter and receiver are working properly and are within range of each other.

- **STRANGULATION HAZARD.** Keep the adapter cords out of the reach of children. Do not use with extension cords.
- **DO NOT** place the Nursery Unit or its cord within your child's reach. Do not put the Nursery Monitor inside a crib or playard.
- **USE ONLY WITH 110-120 VOLT AC ELECTRICAL OUTLETS.**
- **PROTECT THE AC ADAPTER CORDS.** Place them so they are not walked on or pinched by furniture or other items.
- **ALLOW FOR PROPER VENTILATION WHEN UNITS ARE IN USE.** Do not cover the Nursery Unit or Parent Units with any object such as a blanket. Do not place it in a drawer or in any location which would muffle the sound or interfere with the normal flow of air.
- **DO NOT** immerse any part of the Nursery Monitor in water. Clean only with a dry cloth.
- **DO NOT** place unit near water and moisture. Do not use the Nursery Unit outdoors. Do not use the monitor near possible wet areas, such as a bathtub, shower, wash basin, sink, laundry tub, swimming pool, wet basement, etc.
- **KEEP NURSERY MONITOR AWAY FROM HEAT SOURCES,** such as fireplaces, radiators, stoves, and TVs or other appliances. Heat can damage the case or electrical parts.
- **DO NOT** use the monitor if:
 - The adapter cords or plugs have been damaged.
 - The unit has been exposed to liquids.
 - Unit has been dropped or is damaged.
- **DO NOT OPEN THE TRANSMITTER, RECEIVER OR ADAPTER.** No user-serviceable parts inside. Risk of electrical shock, fire or death.

System Setup

Installing a Battery

The Parent's Unit can be operated on 9 volt battery power. An alkaline battery is recommended. Battery changing should only be done by an adult.



Battery Use Tips

- Remove battery from Parent's Unit if it will not be used for a long time.
- Remove a dead battery promptly. A dead battery left in unit may leak, damaging your unit.
- Do not attempt to recharge a non-rechargeable battery.
- A rechargeable battery **CANNOT** be recharged by plugging AC adapter into the Parent's Unit. Remove the battery from unit to recharge it.
- Charging of a rechargeable battery should only be done by an adult.
- Battery power will be conserved when Parent's Unit is powered through AC adapter. It is not necessary to remove battery when using AC adapter.
- Change battery if:
 - Signal reception becomes poor.
 - Static noise develops (also check for appliance interference).

Using AC Adapters

- The Parent's Unit can use either a 9 volt battery or standard 120 volt AC household current. The Nursery Unit uses standard 120 volt AC household current only. The included AC adapters must be used for this purpose.
- To use AC adapters, plug the connector on the cord into the AC adapter jack on the side of the unit. Then plug adapter into a standard wall outlet.
- Use ONLY the Graco adapters included with the unit. Do not use these adapters with other equipment under any circumstances.
- If units do not work, check that AC adapters are plugged into working outlets.
- When electricity is off (from a power failure, etc.), the transmitter will NOT work, since it only operates on AC current.

Selecting Channels

- Check that both Nursery Unit and Parent's Unit are set to the same channel.
- To change channel, slide Channel button to either A or B on BOTH units. If successful, green power light will blink once.

Setting Up the Baby Monitor

1. Check that both Nursery Unit and Parent's Unit are set to the same channel.
2. Place the Nursery Unit within 10 feet (2-3 meters) of your baby. Plug an AC adapter into the jack on the side of the Nursery Unit. Plug it into a working 120 volt AC outlet.
3. Aim the Nursery Unit toward your baby. Check that there are no walls or large objects that could block sound transmission.
4. Turn on the Nursery Unit using the ON/OFF switch. The green power light should come on.
5. Install a 9 volt battery into the Parent's Unit, or plug it into a working 120 volt AC outlet using the other AC adapter.
6. Turn on the Parent's Unit using the volume control dial. The green power light should come on.

Testing the System

It is VERY IMPORTANT to test the system when first set up, and at regular times thereafter. Test the units any time they may have been damaged or have not been used for a long time.

1. If two adults are present, have one take the Parent's Unit to different locations, trying various volume settings, while the other speaks into the Nursery Unit.
2. If only one adult is available, place a ticking clock, radio, or other sound-producing device near the Nursery Unit to test it.
3. When testing, keep the level of your child's sounds in mind, and adjust the volume accordingly.
4. If there is sound interference, switch both the Nursery Unit and the Parent's Unit to the other channel setting.

NOTE: As with all radio frequency devices, transmission range and reception may vary. Your Nursery Monitor uses public airwaves, so it is possible for conversations near the Nursery Unit to be broadcast to other nursery monitors, radios, cordless phones or scanners outside your home. For your privacy, always turn off the Nursery Unit when not in use.

This monitor operates on one or more of the following frequencies:
925.7-927.5 Mhz and 902.5-904.3 Mhz.

Solving Problems

DO NOT ATTEMPT TO MODIFY THE UNIT.

Any modifications to the transmitter and/or receiver can void the operator's authority to operate the equipment.

Most problems have a simple solution.

First, check that:

- Power is turned ON for both units
- Both units are plugged in (or battery is fresh in Parent's Unit)
- Electrical outlet works
- Units are set to same channel
- Volume is turned up on Parent's Unit
- Parent's Unit is in range of the Nursery Unit

No Sound

- Battery dead or weak — replace batteries or use AC adapter.
- Channel settings do not match — set both units to same channel.
- AC adapter not properly connected — check the connections.
- Nursery Unit covered or blocked — remove the obstruction.

Weak Sound

- Parent's Unit too far from Nursery Unit — move closer.
- Large objects blocking the signal — try repositioning Nursery Unit.
- Check that antennas are vertical and are not touched by other objects.
- Volume setting too low — turn it up.

Operation

To Listen To Baby

- Check that Nursery Unit and Parent's Unit are on the same channel.
- Turn on Nursery Unit using the Volume ON/OFF switch.
- Turn on Parent's Unit using the Volume ON/OFF switch.

To Speak to Baby

- Check that Nursery Unit and Parent's Unit are on the same channel.
- Turn on Nursery Unit using the Volume ON/OFF switch.
- Turn on Parent's Unit using the Volume ON/OFF switch.
- On Parent's Unit, press and hold the "Push to Talk Baby" Button. Parent's Unit is ready to transmit when green power light blinks once. (If green light does not blink, you will not transmit to Nursery Unit. Refer to Solving Problems on page 10.)
- Speak into Parent's Unit.

NOTE: When Parent's Unit is transmitting to the Nursery Unit, Parent's Unit will not receive from the Nursery Unit.

Static

- Interference from other electrical equipment — eliminate cause of static (TVs, mixers, computers, fans, fluorescent lights, light dimmers, etc.)
- Parent's Unit too far from Nursery Unit — move them closer.
- Channel settings do not match — set both units to same channel. Try other channel on both Parent's Unit and Nursery unit.

Shrill Sound (Feedback)

- Nursery Unit and Parent's Unit too close together — move them farther apart.
- Volume set too high — lower the volume.

If you cannot solve the problem,

please contact our Customer Service Department:
USA: 1-800-345-4109 Canada: 1-800-667-8184 Montreal: 514-344-3533