






VVX 500/501


VVX 600/601




Note: For more information on your Polycom® VVX® 500 series and VVX 600 series business media phones, see user documentation, including Quick User Guides and User Guides, on your phone's Support page on Polycom Voice Support: <http://support.polycom.com/voice>.

Package Contents


**VVX 500 or VVX 600
Series Phone**


Optional Accessories



AC Power Cord and Adapter

VVX Camera

**VVX Expansion Module
(paper display)**

**VVX Expansion Module
(LCD color display)**

Features




Connect Cables



Connect Stand*


Fully insert the stand into one of the slots on the back of the phone. The slot you choose determines the angle of the phone. For high-angle use, secure the handset with the reversible tab (see **Features**).



*For wallmount installation, an optional accessory is available. For more information, contact your reseller.

Connect Optional Headset

Your phone supports wired and wireless headsets, including electronic hookswitch (EHS) headsets. VVX 600/601 phones also support Bluetooth headsets. For connection directions, refer to your headset documentation. Standard headsets typically use the RJ-9 or USB port, while EHS headsets use the RJ-9 and serial port. The ports are on the back of your phone, as shown in the diagram.



Connect Optional USB Devices

You can attach a USB headset, or a USB flash drive (to record calls, use the Digital Picture Frame feature, or to change the background picture on your phone). To learn more, see your phone's User Guide.

