






PHOTOGRAPH 13
FCC ID: M7QAV-SENDER
SOLDER VIEW OF THE ADAPTOR


PHOTOGRAPH 12
FCC ID: M7QAV-SENDER
COMPONENT VIEW OF THE ADAPTOR



INTERNAL VIEW OF THE ADAPTOR




PHOTOGRAPH 08
FCC ID: M7QAV-SENDER
SOLDER VIEW OF RF MODULE



FCC ID: M7QAV-SENDER

PHOTOGRAPH 07


COMPONENT VIEW OF RF MODULE




FCC ID: M7QAV-SENDER

PHOTOGRAPH 06


SOLDER VIEW OF MAIN BOARD




COMPONENT VIEW OF MAIN BOARD



INTERNAL VIEW OF THE EUI





PHOTOGRAPH 03
FCC ID: M7QAV-SENDER
INTERNAL VIEW OF THE EUT