


INSTALLATION OF THE VEHICLE ANTENNA TUBE

① Push antenna wire through hollow antenna tube.




③ A knot may be tied at the top. (Do not pull wire tight)

NOTE

Controller and Vehicle ANTENNAS are packed within the polyfoam box.

Insert tube into the hole on vehicle

TRANSMITTER CONTROL FUNCTIONS




The Vehicle Light will be ON when pressing FORWARD or REVERSE. (MONSTER PATROL & SNAKE BITE only)

CONTROL RANGE




When the vehicle is driven beyond radio signal range, there could be a loss of control. The distance range for most radio-controlled vehicles is approximately between 25m to 50m, when operating outdoor. (The range is also subject to interference.)

Hold transmitter antenna up high for best reception.



INTERFERENCE

Erratic behavior or loss of control of vehicle is sometimes caused by vehicle operated in an area surrounded by high-tension wires, telephone poles with high-voltage transformers, or even certain buildings or cars operating CB radios. If you encounter this type of behavior, move to a better location to drive your vehicle.



VEHICLE FUNCTION


Monster Patrol

Samson

Bigfoot

Snake Bite

Full Function = Sound = Light =



OPERATING AND CARING FOR YOUR VEHICLE


Any of the following conditions may interfere with the behavior and function. The transmitter signals can easily be interrupted. Caring for your transmitter and vehicle is illustrated on these pages. Improper handling may hamper the performance of the vehicle.




Keep vehicle away from wet surfaces or rain.

Do not abuse your vehicle!

Remember to avoid water, heat, sand and high impact crashes! Any of the following conditions illustrated below may interfere with the behavior and function.




Avoid running on thick carpet or dusty floors.




Avoid collision on hard surface.


Avoid running 2 vehicles of the same frequency. Always run one at a time unless you purchase vehicles with different frequencies.




DO NOT carry the vehicle by pulling the antenna wire.



Keep vehicle away from sandy or dusty areas.



DO NOT operate your vehicle on the streets!



Save Battery Life
Make sure that the vehicle & transmitter are turned off when not in use.

TROUBLE SHOOTING

PROBLEM	CAUSE	CORRECTION
VEHICLE DRIVES SLOWLY	-WEAK BATTERIES IN VEHICLE BATTERIES ARE OLD, MISMATCHED OR NOT ALKALINE.	-REPLACE VEHICLE BATTERIES WITH FRESH ALKALINE OR RECHARGE THE BATTERY PACK
POOR STEERING CONTROL	-LOW BATTERY IN TRANSMITTER -FLOOR TOO SLICK OR TOO DUSTY	-REPLACE NEW BATTERY -TRY ASPHALT OR CONCRETE
NO POWER	-INCORRECT PLACEMENT OF BATTERIES -RUSTY CONTACTS -BATTERY CONTACT TOO LOOSE -POWER SWITCH "TRY-ME" MODE	-CHECK +/- POLARITY -CLEAN TERMINAL WITH SANDPAPER -PRY METAL CONTACT OUT WITH SMALL SCREWDRIVER -CHECK POWER SWITCH TO VEHICLE TURNED ON.
POOR RANGE CONTROL	-WEAK BATTERIES IN TRANSMITTER OR VEHICLE -STRONG INTERFERENCE AT THE SURROUNDED AREA -TRANSMITTER ANTENNA IS NOT SCREWED IN SECURELY -TRANSMITTER ANTENNA IS NOT EXTENDED TO THE FULL LENGTH	-REPLACE WITH NEW BATTERIES -MOVE TO A BETTER LOCATION TO DRIVE YOUR VEHICLE -SECURE THE TRANSMITTER ANTENNA -EXTEND TRANSMITTER ANTENNA TO FULL LENGTH

Modifications not authorized by the manufacturer may void users authority to operate this device

CAUTIONELECTRICALLY OPERATED PRODUCT! NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS

OF AGE AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK.

Note: This equipment has been tested and found to comply with the limits for Class E digital devices, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment to a different power outlet, which the receiver is connected to a different power outlet.
-Consult the dealer or an experienced radio/TV technician for help.


81001, 31002, 81003, 81004, 81005, 81006



OPERATOR'S MANUAL FULL FUNCTION RADIO CONTROL


BATTERY INSTALLATION

TRANSMITTER



VEHICLE

② Place batteries as shown



HINTS WHEN USING BATTERIES

1. Do not use old and new batteries or batteries of different types at the same time. When charging batteries, always replace with a new set of batteries.
2. Do not use non-rechargeable batteries with rechargeable batteries or rechargeable batteries of different capacities.
3. Observe the polarity marks on the batteries and match them according to the battery compartment markings.
4. Remove all batteries from the transmitter and the vehicle when not in use for an extended period of time.
5. Misuse of the built-in rechargeable battery may lead to heat, break, fire or leak of electrolyte. Please pay enough attention to the following cautions.
6. Please charge the battery only when it's fully stopped. Never charge a vehicle that has been fully charged to avoid danger caused by excessive charging.
7. Stop using whenever it's wet to avoid short-circuit.
8. Never throw the battery into water or fire or disassemble or weld it.
9. Do not use, charge or store the toy near a fire source or in hot and humid place.
10. Use only special charger for charging purpose.