





CBS-2100 CH. Display PCB Assembly PCB-03

FILE: CH Display Board.PCX

Date: 13-4-1999


DWN BY: TUNG

CBS2100 PLL Circuit PCB Assembly PCB-07



Remark: PCB-02 = CH. Switch/Display Drive Assembly

CBS2100 PLL Circuit PCB Assembly PCB-07	
FILE: PLL Circuit Board.PCX	
Date: 13-4-1999	DRAWN BY: TUNG




CBS-2100 Clear Drive PCB Assembly PCB-08

FILE: Clear Drive Board.PCX

Date: 13-4-1998

DWN BY: TUNG




CBS-2100 LEVER SWITCH PCB ASSEMBLY PCB-09

FILE: Lever Switch Board.PCX

Date: 13-4-1999 DWN BY: TUNG

PA. PRE-AMP.

BOARD




CBS-2100 PA. PRE-AMP. PCB ASSEMBLY PCB-10

FILE: PA PRE-AMP Board.PCX

Date: 13-4-1999 DWN BY: TUNG




SCHEMATIC DIAGRAM MODEL : CBS-2100



CBS-2100 BASE STATION
TRANSCEIVER BOARD (MAIN PCB) ASSEMBLY

Date: 12-4-99




PCB LAYOUT (Copper Side)

CBS-2100 BASE STATION

TRANSCEIVER BOARD (MAIN PCB) ASSEMBLY

Date: 12-4-99



COMPONENT LOCATION

REMARK: This is a common part PCB for different transceiver models.

Some components are not required and not installed in the CBS2100.

Details in installed components can be found in the Main PCB Parts List.