

3.2.10.21. \$MSCLS	Set GPRS Multislot Class
Command Function	This command is used to set the GPRS multislot class.
Command Functional Group	Equipment Information
Command Format Query Response	AT\$MSCLS=? \$MSCLS: (1-12) OK
Write Format Response	AT\$MSCLS=<msclass> OK
Read Format Response	AT\$MSCLS? \$MSCLS: <msclass> OK
Execution Format Response	N/A N/A
Parameter Values	
<msclass>	1-12
Reference	N/A
Standard Scope	Optional
Enfora Implementation Scope	Full
Notes	The value is saved when using AT&W command. To return to default MS class, use AT&F command.