

BC

User's Guide MO163

Please read the following instructions and warnings carefully. Keep these instructions for future reference. Contains non-replaceable lithium battery. Tools required for mounting camera: Phillips screwdriver and drill with 3/16" size bit.

Home & System Requirements

- Wireless internet (Wi-Fi) with >1mbps download/upload speeds
- Smart phone or tablet
- Check your phone capability at www.safety1st.com/devicecheck which will direct you to the app store and our app

WARNING!

STRANGULATION HAZARD - Children have STRANGLED in cords. Keep cords out of reach of children (more than 3 feet (0.9 m) away). Use Wall clips provided to secure cord away from baby's reach. Only use the AC adapter provided by the manufacturer. NEVER use an extension cord with the AC adapter.

- For indoor use only. To reduce the risk of fire or electrical shock, **DO NOT** expose this product to water or moisture. **DO NOT** use monitor near water (such as bath tub, sink, etc.) or submerge in water.
- This monitor is not intended to be used as a medical monitor and its use should not replace proper adult/parental supervision. You should check your child's activity at regular intervals as this monitor will not alert parents to the silent activities of a child.
- NEVER** attempt to disassemble the product. This is dangerous and will void the warranty. Product contains a non-replaceable Lithium Ion battery.
- Test monitor periodically when in use and changing locations.
- Use only the adapter supplied with this product. Incorrect adapter polarity or voltage can seriously damage the product.
- To prevent entanglement and overheating, **DO NOT** use extension cords.
- The adapter may become slightly warm to the touch during operation. This is normal.
- ALWAYS** unplug the AC adapter from the wall during extended periods of non-use.
- Check to make sure wall outlet plates are not unusually hot to the touch. If they are, immediately unplug cords from these outlets. Check that all outlet connections are in good condition so that adapter is not loose or that no wiring is exposed. Have a qualified, licensed electrician or that no wiring is exposed.
- This baby monitor allows internet users to hear or view activity. Use the security feature included with this device to restrict internet viewership.
- DO NOT** place adapter/wall plug under a window where a child might use it to step on and/or to reach something that might be dangerous.
- Adult assembly is required. Keep small parts away from children when assembling. Exercise care when unpacking the product.
- This product is not a toy. **DO NOT** allow children to play with it.

BATTERY WARNING!

- Failure to follow these warnings could result in fire, electric shock, injury, or damage to the product or other property.
- DO NOT** attempt to remove or replace this battery from the product. You may damage the battery, which could cause overheating and/or injury.
- Any tampering with the battery can cause serious harm or injury.
- Check battery life regularly.
- DO NOT** use in portable mode when battery is low.
- Batteries **MUST** be recycled or disposed of properly. See *General Information* for further direction.
- Keep product away from heat and fire as it may get damaged, catch fire or explode.
- NEVER** charge battery with unit unattended. Keep away from flammable surfaces during charging.
- Battery should only get slightly warm during charging. If the battery becomes hot, smokes or gives off an odor during charging, **STOP** charging immediately and contact the manufacturer.

THE USER SHOULD NOT ATTEMPT TO SERVICE OR REPAIR THE MONITOR. ALL SERVICING SHOULD BE REFERRED TO CONSUMER CARE AT www.safety1st.com/monitorsupport.

It is essential to check reception regularly.

Monitor uses encrypted transmission over FCC managed frequencies. Always remember to password protect your Wi-Fi router.

- IMPORTANT SAFETY INSTRUCTIONS**
- VENTILATION:** **DO NOT** block ventilation openings. **DO NOT** place on a bed, sofa, rug or similar surface. **DO NOT** place in a book case or cabinet that may restrict air flow.
 - HEAT:** The Monitor should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat. Also keep these components out of direct sunlight.
 - POWER CORD PROTECTION:** The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. Pay particular attention to the cord at the plug, convenience receptacle, and at the point it exits from the Monitor.

- FCC/IC Information**
FCC Information
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Note:** This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These Limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning this equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by Dorel Juvenile Group can void your authority to operate this equipment under Federal Communications Commission's rules.

Use of other accessories may not ensure compliance with the FCC exposure guidelines.

CAUTION: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body

IC Information
This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power

IC Information, continued
(e.i.r.p.) is not more than that necessary for successful communication.

This Class B digital apparatus complies with Canadian ICES-003.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfy-ing RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the ISED. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The high-est SAR value reported under this standard during product certification for use when properly worn on the body.

- Set Up**
- Plug In Camera**
- Connect the longer micro USB power cable with power adapter to camera's port.
 - Plug the power adapter into a suitable wall socket.
 - Wait for the Camera LED to blink purple.

- Audio Parent Unit**
- Connect the shorter micro USB power cable to the port of the audio parent unit.
 - Plug the USB side of the power cable into any suitable adapter, laptop or other electronic device and charge fully before using it.
 - Press the power button to turn the unit on.
 - Wait for the audio Parent Unit LED on the power button to blink blue.

Install Smart App Download the Safety1st App by searching for Safety1st in the app store. You can also visit www.safety1st.com/monitorsupport in any browser on your smart device.

Note: If you already use the Safety1st App, make sure that you are using the latest version. To find out if an update is available, review the settings within the app or go to the App store and search for Safety1st.

Setup In your smart device, follow the screens in the Safety1st App for setup at www.safety1st.com/apps.

Wi-Fi Connectivity

Check the Wi-Fi signal strength from your internet service provider. To avoid signal interference or echoes, ensure that there is enough distance between your device and the Camera. Use of other 2.4GHz products, such as Bluetooth systems or microwave ovens, may cause interference with this product. Also avoid placement near major electrical equipment, large metal or concrete objects or walls. Keep the Camera at least 5 ft (1.5 m) away from these types of products, or turn them off if they appear to be causing interference.

App Upgrade

You can find the latest version of Safety1st App by visiting your mobile device's app store (e.g.: iTunes App Store, Google Play). From there, you can see what's new with the app and install the latest version.

Occasionally, Safety1st will send you notifications that a newer version of the Safety1st app is now available. While some of the upgrades simply keep your system running efficiently, some are critical to system functionality. We strongly recommend that you complete the upgrade as soon as possible. Software upgrades will only be performed in Wi-Fi mode.

Microphone – For audio input

Status LED indicator - Shows the camera status

Lens – Provides a clear, wide angle view

IR LED – Turns on/off night vision automatically

Pairing Button – Press and hold 3 seconds

Micro USB Charging Port

Reset Hole - Reset the camera

Speaker

Swivel Joint – Tilt the camera to maximize view

Rubber Base – Increases friction to fix camera on smooth surface

Mounting Slot – Attach the camera to screws

Pairing Button

MicroUSB plug

Microphone

Speaker

Power Button

Camera Power Cord – 3m (10ft)

Parent Unit Adapter Cord – 1m (3ft)

Volume down

Volume up

Push to talk

Light on/off

Screws (7)

Drywall anchors (7)

Wall clips (5)

Using your Baby Monitor

Note: Explore the features and functionality within the Safety1st App. Use the in-app tutorial to help guide you where required.

WARNING!

STRANGULATION HAZARD - Children have STRANGLED in cords. Keep cords out of reach of children (more than 3 feet (0.9 m) away). Use Wall clips provided to secure cord away from baby's reach. Only use the AC adapter provided by the manufacturer. NEVER use an extension cord with the AC adapter.

Wall Mount

- Mark the location on the wall where the camera will be mounted.
- Using a 3/16" drill bit drill a hole 1.0" (2.54 cm) deep.
- Insert drywall anchor into hole. Lightly tap with a hammer if necessary until the drywall anchor is flush with the wall surface.
- Using a screwdriver, hand screw a screw into the drywall anchor leaving approximately 0.25" (0.63 cm) sticking out.
- Insert the key hole on the base of the camera onto the screw on the widest part.
- Slide the camera DOWN on the screw locking the camera into place. **DO NOT** slide the camera UP as this will result in the camera falling off of the wall.
- Use the provided wall clips to position and secure the cord 3 ft (0.9 m) away from the crib. Repeat steps 2, 3 and 4 to place the wall anchors into the wall. Place each wall anchors 2 ft (0.61 m) apart.
- Place cords into the wall clips and pull tightly to align wall clip hole to wall anchor.
- Close the top cover to secure the cord in place and insert provided screw and tighten into wall anchor.

Table Top

- Determine camera location keeping the camera at least 3 ft (0.9 m) away from crib. The Camera should be placed on a flat surface, such as a chest of drawers, desk or shelf.
- Use the provided wall clips to position and secure the cord 3 ft (0.9 m) away from the crib.

Resetting Camera and Parent Unit

If you have Camera and Parent Unit setup issues, then the Camera and Parent Unit may need to be reset.

If you received your camera and Parent Unit from a friend/family or other third party the camera and Parent Unit should be removed from their account before attempting to setup the camera and Parent Unit with your account

Please reset the Camera and Parent Unit with the following procedures:

- Find a paperclip or similar tool.
- Insert the tool straight into the reset button hole.
- The button will compress and you will hear a subtle click
- Hold the button down for at least 3 seconds.
- Release the button and wait for the camera to reboot.
- The process is complete when the light is solid red.
- You can add your Camera and Parent Unit again by following the steps within the app.

Troubleshooting

A blinking red light on your camera indicates that your unit is disconnected from Wi-Fi. Check your Wi-Fi connection.

Visit www.safety1st.com/monitorsupport for frequently asked questions and video references. If your product is not working properly consult the quick start guide or owners manual. Check your internet service connectivity. Check online FAQ and community at www.safety1st.com/monitorsupport Tap the In-App support icon on your smart device.

General Information

Baby Monitor Care
Cleaning

Clean product with a slightly damp cloth or with an anti-static cloth. Never use cleaning agents or abrasive solvents.

Do not clean any part of the product with thinners or other solvents and chemicals - this may cause permanent damage to the product which is not covered by the warranty.

Keep product away from hot, humid areas or strong sunlight, and do not let it get wet. Every effort has been made to ensure high standards of reliability of your product. However, if something does go wrong, please do not try to repair it yourself - contact Customer Service for assistance.

Disposal

At the end of the product life cycle, you should not dispose of this product with normal household waste. Take this product to a collection point for the recycling of electrical and electronic equipment. Batteries must be recycled or disposed of properly.

Some of the product materials can be re-used if you take them to a recycling point. By reusing some parts or raw materials from used products you make an important contribution to the protection of the environment. Please contact your recycling center in case you need more information on the collection points in your area.

1 Year Warranty

Dorel Juvenile Group will replace or repair (at our option) your unit free of charge from 12 months from the date of purchase if the unit is defective in workmanship or materials. To make a claim, contact Consumer Care at 1-800-544-1108 or text us at 812-566-2525 within one year of purchase from an authorized retailer. Please be prepared to validate proof of purchase with your claim. In the absence of a purchase receipt, the warranty will be considered 12 months from the date of product manufacture. This warranty does not apply to normal wear or damage from misuse, abuse, improper storage and handling, installation, accident, unauthorized repair or alteration, tampering, contact with liquid, water, rain, extreme humidity, sand, dirt, extreme heat, placement or testing not in accordance with the user guide placement or testing not in accordance with the user guide. Please contact our Consumer Relations department for more details.

© 2017 Dorel Juvenile Group, Inc. Safety 1st™ and the Safety 1™ logo and design are trademarks of Dorel Juvenile Group, Inc. www.safety1st.com/monitorsupport Styles and colors may vary. Los estilos y los colores pueden variar. Made in CHINA. Hecho en CHINA. Distributed by (distribuido por) Dorel Juvenile Group, Inc., 2525 State St., Columbus, IN 47201-7494. Dorel Juvenile Canada, 2855 Argenta Road, Unit 4, Mississauga, ON, L5N 8G6 10/31/17 4358-xxxx

Importado y Distribuido en Chile por: Comercial e Industrial Sifta S.A. - San Ignacio 0201 / Parque Industrial Portezuelo Quilicura, Santiago Chile. Fono (562) 2339 9000. En Perú por: Comexa S.A. - Los Libertadores 455 - San Isidro, Lima - Perú. Fono (511) 4469014. En Centro América, Caribe y Ecuador por: Best Brands Group S.A. - Av. Balboa, Bay Mall Plaza, Planta Baja, local 9, Panamá. - Fono: (507) 300 2884. En Colombia por: Baby Universe S.A.S. - Vía 40 No. 77-29, Barranquilla, Colombia - Fono: (575) 353 1110

Importador: DJGM, S.A. DE C.V. Gabriel Mancera No. 1041 Col. Del Valle Delegación Benito Juárez C.P. 03100 México, D.F. C.F. DJG1403095GN9 Tel. (55) 67199202

