



**SCAN
HERE**
FOR
SUPPORT



You can also:


Send Us a Text: 1-812-203-4747
(US and Canada Only
Carrier Fees May Apply)

Find Us Online: www.safety1st.com

Email Us: support@djgusa.com

Give Us a Call: 1-800-544-1108
(Toll Free)

WiFi Baby Monitor



WARNING:

STRANGULATION HAZARD -


Children have **STRANGLED** in cords. Keep this cord out of reach of children (more than 3 feet (0.9 m) away). Do not remove this tag. Use wall clips provided to secure cord away from baby's reach. Only use the AC adapter provided by the manufacturer. **NEVER** use an extension cord with the AC adapter.



5.17.21 4358-8154B MODEL: M0173

In The Box

Please read the following instructions and warnings carefully.
Keep these instructions for future reference.



1x Monitor



1x Wall Mount



1x Reset Tool



1x Power Adapter



3x User Manual
(English, French,
& Spanish)



1x Micro
USB Cable
9' 10" (3m) long



7x
Screws



7x Drywall
Anchors




5x Wall
Clips

Tools required for mounting monitor (not included):

- Phillips screwdriver
- Drill with 3/16" size bit
- Hammer
- Pencil

1

Features




Status LED

IR LEDs (behind faceplate)

Lens

Microphone



Back of Monitor

Reset Button

Speaker

Micro SD Card Slot
(on side of monitor)

Micro USB Power Port

2

Getting Started

Download Safety 1st App

Download the **Safety 1st Connected** app by searching for Safety 1st in the app store.



Setup

1. Connect the micro USB cable with power adapter to monitor. Status LED will flash red and the device is now ready for pairing.
2. On your mobile device, follow the step by step instructions in the **Safety 1st Connected** app for setup.
3. Once paired, the status LED will turn blue.
4. Explore the features and functionality within the **Safety 1st Connected** app.

Wi-Fi Connectivity

A 2.4GHz Wireless Internet with > 2Mbps available download/upload speeds is required.

Check the Wi-Fi signal strength from your internet service provider.

To reduce signal interference or echoes, avoid placing the monitor near major electrical appliances, large metal or concrete surfaces.

3

Cleaning & Disposal

Cleaning

Clean product with a slightly damp cloth or with an anti-static cloth. **ALWAYS** unplug from electrical outlet before cleaning.

NEVER USE cleaning agents or abrasive solvents. **DO NOT** clean any part of the product with thinners or other solvents and chemicals - this may cause permanent damage to the product which is not covered by the warranty.

Keep product away from hot, humid areas or strong sunlight, and do not let it get wet.

Every effort has been made to ensure high standards of reliability of your product. However, if something does go wrong, **please do not try to repair it yourself** - contact Consumer Care for assistance.

Disposal

At the end of the product life cycle, **you should not dispose of this product with normal household waste**. Take this product to a collection point for the recycling of electrical and electronic equipment.

Some of the product materials can be re-used if you take them to a recycling point. By reusing some parts or raw materials from used products you make an important contribution to the protection of the environment. Please contact your recycling center in case you need more information on the collection points in your area.

4

Mounting Monitor

Tools required for mounting monitor (not included):

- Phillips screwdriver
- Hammer
- Drill with 3/16" size bit
- Pencil

WARNING:

STRANGULATION HAZARD -


Children have **STRANGLED** in cords. Keep this cord out of reach of children (more than 3 feet (0.9 m) away). Do not remove this tag. Use wall clips provided to secure cord away from baby's reach. Only use the AC adapter provided by the manufacturer. **NEVER** use an extension cord with the AC adapter.



5

Wall Mounting

Before Wall Mounting the monitor, download the app and complete the pairing process. This will help ensure optimal placement. The following instructions are for securely mounting to a drywall surface.




1. Examine the room and determine the optimal placement on the wall. Mark this location with a pencil. **IMPORTANT:** Ensure that the baby monitor is at least 3 ft (0.9 m) away from the crib.
2. Place the included wall mount onto the wall at the marked location, ensuring the arrow is pointing upwards. Using a pencil, make a mark through the two screw holes. Put the wall mount to the side for later use. 
3. Using a 3/16" drill bit, drill a hole 1.0" (2.54 cm) deep on the pencil marks. **DO NOT** drill through the wall mount holes.
4. Insert drywall anchor into the hole. If necessary, lightly tap with a hammer until the drywall anchor is flush with the wall surface. **Note:** If mounting to a wall stud, drywall anchors are not required.
5. Align the holes of the wall mount with the drywall anchors and using a screwdriver, hand tighten a screw into each of the drywall anchors. **DO NOT** over tighten. 

continued on next page

6


6. Locate the hole underneath the base of the monitor and place it on the wall mount.
7. Applying light pressure to the base, slide the monitor **DOWN** on the wall mount until it clicks firmly into place. **DO NOT** pull on the monitor head. Rotate and tilt the monitor to ensure it is fully attached to the wall mount.
 - a. To remove the monitor from the wall, push up on the base until it releases from the mount. **NEVER** leave the monitor hanging on the wall mount without clicking in place.
8. Before proceeding to the next step. Ensure that the viewing angle is to your liking by verifying the app. Rotate and tilt the monitor as needed.
9. **WALL CLIPS:** Use the included wall clips to secure the cord at least 3 ft (0.9 m) away from the crib:
 - a. Repeat steps 3 and 4 to install the wall anchors into the drywall. Ensure that wall anchors are placed 2 ft (0.61 m) apart.
 - b. Align the holes of the provided wall clips with the wall anchors and using a screwdriver, hand tighten a screw into each wall clip.
 - c. Place cords into the wall clips and pull tightly to align wall clip hole to wall anchor.



- d. Close the top cover to secure the cord in place and insert provided screw and tighten into wall anchor.
- e. The cord can also be tucked under the slots on the left or right side of the monitor's base for additional cord management.



Flat Surface Mounting

1. Determine an optimal monitor placement, keeping the monitor and power cord at least 3 ft (0.9 m) away from crib. The monitor should be placed on a flat surface, such as a chest of drawers, a desk, or a shelf.
 
2. Before proceeding to the next step. Ensure that the viewing angle is to your liking by verifying the app. Rotate and tilt the monitor as needed.
3. Follow **Step 9 a-d of Wall Mounting: WALL CLIPS**. Use the included wall clips to secure the cord at least 3 ft (0.9 m) away from the crib. This will help reduce the chance of the monitor slipping, sliding, rotating or falling over.

WARNING:

For indoor use only. To reduce the risk of fire or electrical shock, **DO NOT** expose this product to water or moisture. **DO NOT** use monitor near water (such as bath tub, sink, etc.) or submerge in water.

This monitor is not intended to be used as a medical monitor and its use should not replace proper adult/parental supervision. You should check your child's activity at regular intervals as this monitor will not alert parents to the silent activities of a child.

NEVER attempt to disassemble the product. This is dangerous and will void the warranty.

Test monitor periodically when in use and changing locations.

9

Use only the adapter supplied with this product. Incorrect adapter polarity or voltage can seriously damage the product.

To prevent entanglement and overheating, **DO NOT** use extension cords.

The adapter may become slightly warm to the touch during operation. This is normal.

ALWAYS unplug the AC adapter from the wall during extended periods of non-use.

Check to make sure wall outlet plates are not unusually hot to the touch. If they are, immediately unplug cords from these outlets. Check that all outlet connections are in good condition so that adapter is not loose or that no wiring is exposed. Have a qualified, licensed electrician check the wiring as soon as possible.

continued on next page

10

This baby monitor allows internet users to hear or view activity. Use the security feature included with this device to restrict internet viewership.

DO NOT place adapter/wall plug under a window where a child might use it to step on and/or to reach something that might be dangerous.

Adult assembly is required. Keep small parts away from children when assembling. Exercise care when unpacking the product.

This product is not a toy. **DO NOT** allow children to play with it.

THE USER SHOULD NOT ATTEMPT TO SERVICE OR REPAIR THE MONITOR. ALL SERVICING SHOULD BE REFERRED TO CONSUMER CARE.

It is essential to check reception regularly.

Monitor uses encrypted transmission over FCC managed frequencies. **Always remember to password protect your Wi-Fi router.**

11

IMPORTANT SAFETY INSTRUCTIONS

- **VENTILATION:** **DO NOT** block ventilation openings. **DO NOT** place on a bed, sofa, rug or similar surface. **DO NOT** place in a book case or cabinet that may restrict air flow.
- **HEAT:** The monitor should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat. Also keep these components out of direct sunlight.
- **POWER CORD PROTECTION:** The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. Pay particular attention to the cord at the plug, convenience receptacle, and at the point it exits from the monitor.

FCC/IC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation.

continued on next page

12

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning this equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by Dorel Juvenile Group can void your authority to operate this equipment under Federal Communications Commission's rules.

Use of other accessories may not ensure compliance with the FCC exposure guidelines.

CAUTION: This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

IC Information

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate

using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This Class B digital apparatus complies with Canadian ICES-003.

Warranty

Dorel Juvenile Group warrants this product against defective materials or workmanship for one year from the date of original purchase. For more information or to make a claim, visit www.safety1st.com/warranty.

©2021 Dorel Juvenile Group, Inc. Safety 1st™ and the Safety 1st logo and design are trademarks of Dorel Juvenile Group, Inc. (800) 544-1108 www.safety1st.com. Styles and colors may vary. Les styles et les couleurs peuvent varier. Los estilos y los colores pueden variar. Made in China. Fabriqué en Chine. Hecho en China Distributed by (distribué par/distribuido por) Dorel Juvenile Group, Inc., 2525 State St., Columbus, IN 47201-7494. Dorel Juvenile Canada, 2855 Argentia Road, Unit 4, Mississauga, ON L5N 8G6. Importado y Distribuido en Chile por: Comercial e Industrial Silfa S.A. - San Ignacio 0201 / Parque Industrial Portezuelo Quilicura, Santiago Chile. Fono (562) 2339 9000. En Perú por: Comexa S.A. - Los Libertadores 455 - San Isidro, Lima - Perú. Fono (511) 4469014. En Centro América, Caribe y Ecuador por: Best Brands Group S.A. - Av. Balboa, Bay Mall Plaza, Planta Baja, local 9, Panamá. - Fono: (507) 300 2884. En Colombia por: Baby Universe S.A.S. - Via 40 No. 77-29, Barranquilla, Colombia - Fono: (575) 353 1110 Importador: DJGM, S.A. DE C.V. Gabriel Mancera No. 1041 Col. Del Valle, Benito Juárez C.P. 03100 México, Ciudad de México R.F.C. DJG140305GN9 Tel. (55) 67199202 5/21 4358-8154B MODEL: M0173

