

Safety 1st®

Grow-With-Me Intercom Monitor
Owner's Guide

No. 49240

Introduction

Thank you for purchasing the Safety 1st Grow-With-Me Intercom Monitor. This is a multifunctional, state-of-the-art monitor that features a convenient intercom mode that allows two way communication between the parent's unit and the baby's unit. This unique monitor allows you to soothe baby with your voice and communicate directly back and forth as the child grows older, thus offering you years of extended use.

The baby's unit has continuous transmission that sends your baby's sounds to the parent's unit. The parent's unit contains a talk switch with a lock-out feature for parental control, thus providing complete 2-way communication. By using 900MHz technology, these units provide superior clarity with an extended range of up to 1000 feet. The baby's unit can also be simply converted to a fully portable toddler unit by removing it from its base and easily clipping it to the child's clothing. Both units feature unique "rubberized" bases that allow them to be placed on dresser tops and counters more securely. The parent's unit may be clipped to a belt for additional mobility, and utilizes an audio and visual alarm to indicate signal loss. The units have 4 channels to minimize outside interference and offer additional privacy.

The parent's unit may be used with AC power or with 4 AAA batteries (not included) for portability. The baby's detachable transmitter is recharged from its AC powered base, providing hours of continuous portable use.

We are sure that you will find the Grow-With-Me Intercom Monitor convenient and easy to use. To insure that you benefit from all of the great features that your monitor offers, and to make sure that you use it properly, we urge you to:

PLEASE READ all instructions carefully before using this product and keep these instructions for future reference. If you have any questions, please call our consumer relations number at (800) 721-3389

CAUTION:

- THE GROW-WITH-ME INTERCOM MONITOR IS NOT INTENDED TO REPLACE RESPONSIBLE AND PROPER PARENTAL SUPERVISION.
- YOU SHOULD CHECK YOUR CHILD'S ACTIVITY AT REGULAR INTERVALS AS THIS MONITOR WILL NOT ALERT PARENTS TO THE SILENT ACTIVITIES OF A CHILD.

WARNING: Changes or modifications to this unit not expressly approved by Safety 1st, Inc. could void user's authority to use equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Safety Instructions

(caution flags/graphics)

WARNING: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVERS.

NO SERVICEABLE PARTS INSIDE.

REFER TO SAFETY 1ST CONSUMER RELATIONS: (800) 723-3065.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS PRODUCT TO WATER OR MOISTURE.

NEVER TOUCH THE END OF THE ADAPTER CORD WHEN THE ADAPTER IS PLUGGED INTO AN ELECTRICAL OUTLET.

READ INSTRUCTIONS: All the safety instructions should be read before the Grow-With-Me Intercom Monitor is operated.

RETAIN INSTRUCTIONS: The safety instructions should be retained for future reference.

HEED WARNINGS: All warnings on the Grow-With-Me Intercom Monitor and operating instructions should be adhered to.

FOLLOW INSTRUCTIONS: All operating instructions should be followed.

WATER AND MOISTURE: The Grow-With-Me Intercom Monitor should not be used near water, for example, near a bath tub, wash bowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool, etc.

VENTILATION: The Grow-With-Me Intercom Monitor should be placed so that its location does not interfere with proper ventilation of the unit. For example, it should never be situated on a bed, sofa, rug or similar surface that may block ventilation.

HEAT: The Grow-With-Me Intercom Monitor should be kept away from heat sources such as radiators, heat registers, stoves or other appliances that produce heat.

AC POWER SOURCE: The Grow-With-Me Intercom Monitor should be connected only to the AC adapters supplied with the unit.

POWER CORD PROTECTION: The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. Pay particular attention to the cord at the plug, convenience receptacle, and at the point it exits from the AC adapters.

CLEANING: Use a dry cotton cloth to keep the 2-Way Grow-With-Me Monitor free from dust. Do not use water!

NON-USE PERIODS: The power cords of the Grow-With-Me Intercom Monitor should be unplugged from the outlet when unused for long periods of time. The batteries should also be removed during these periods.

OBJECT AND LIQUID ENTRY: Care should be taken so that objects do not fall onto the product, and liquids are not spilled into the enclosure through the openings.

DAMAGE REQUIRING SERVICE: The Grow-With-Me Intercom Monitor should be serviced by qualified personnel when:

A: The power supply cord or plug has been damaged.

B: Objects have fallen or liquid has been spilled onto the product.

C: The Monitor has been exposed to rain.

D: The Monitor does not appear to operate normally or exhibits a marked change in its performance.

E: The Monitor has been dropped or the enclosure damaged.

THE USER... CHILD.

Contents

Parent's Unit (Receiver)

Baby's Unit with detachable portable toddler's unit (Transmitter)

Rechargeable battery (included with portable toddler's unit)

(2) AC Adapters

(LD 0f: separated baby unit; parent unit; two AC adapters; rechargeable battery)

Batteries Required (Optional)

(4) AAA alkaline batteries (not included)

Features and Components - Parent's unit

- 1 Power/Volume Dial
- 2 Channel Switch
- 3 Talk/Talk-Lock-out Buton
- 4 Power/Low Battery Indicator
- 5 Sound Lights/Audio-Visual Out-Of-Range Alarm
- 6 Antenna
- 7 Speaker
- 8 Microphone
- 9 AC Adapter Jack
- 10 Belt Clip
- 11 Keyhole for optional wall mounting
- 12 Battery Compartment (4 - AAA)

(LD of parent's unit: front, left side, right side, back)

Parent's Unit (Receiver)

1 2 3 4 5 6 7 8 9 10 11 12

Features and Components - Baby's Unit

- 1 Antenna
- 2 Power/Low Battery/Recharging Indicator
- 3 Detachable Portable Toddler Unit
- 4 Base Unit
- 5 Speaker
- 6 Microphone
- 7 Child-resistant Clothing Clip
- 8 AC Adapter Jack
- 9 Channel Selector (Inside Rechargeable Battery Compartment)
- 10 Recharge Battery Compartment
- 11 Rechargeable Battery
- 12 LED Power Indicator (Base Unit)

(LD of Child's unit: assembled front; detached fronts; assembled back; portable transmitter back)

Baby's Unit (Transmitter)

1 2 3 4 5 6 7 8 9 10 11

AC Adapters

The AC Adapters are a low voltage power source that allows you to use your household electricity to run the Parent's and Baby's Units. They connect to the AC Adapter Jacks in the Parent's Unit and the Baby's Base Unit, and plug into any standard electrical outlet in your home.

CAUTION: These adapters were made with a specific design for Safety 1st Grow-With-Me Intercom Monitor. They cannot be used with any other appliance. Never use a different type of adapter with this monitor.

WARNING: Never touch the end of the adaptor cord when the adaptor is plugged into an electrical outlet.

(LD of AC Adapter)

AC Adapter

Operating Your Grow-With-Me Intercom Monitor

Follow these instructions to operate your Grow-With-Me Intercom Monitor. Reference the illustrations on pages 2 & 3 for the location of all features described in these instructions.

Baby's Unit:

For best results, place the Baby's Unit on a table near the crib or bed. It should be facing the baby's head as close to the crib as possible, but out of baby's reach.

STEP 1 Plug the round end of adapter cord into the jack on the Baby's base unit, then plug the the adapter into an electrical outlet . The LED Light on the Base should be illuminated and solid green and the LED Light on the detachable toddler unit should be illuminated and a solid green (if fully recharged). LED indicator will be solid red if toddler unit is recharging.

STEP 2 Remove the battery compartment door on the back of the baby's Base unit. Select one of the four channel options. If you experience static or noise interference select one of the remaining three channels and note your selection on a separate piece of paper. Replace the Battery compartment door.

STEP 3 As baby grows older and mobile detach portable toddler unit fom Base Unit as shown.

(LD of hand separating pieces)

STEP 4 Using Child Resistant Clip on back of portable toddler unit, attach to baby's clothing as shown.

(LD of hand attaching monitor to clothing)

STEP 5 Portable toddler unit normally blinks green when it is out of its base. After several hours of continuous use the LED Light on the portable toddler's unit will blink red, indicating low battery-needs recharging. Return toddler's unit to Base Unit. When reattached and switched ON, LED on portable toddler's unit will glow solid green. When Base Unit is switched OFF, LED will change to solid red, indicating recharging in progress. Overnight recharging is recommended. The portable toddler's unit may now be re-separated from the Base Unit and reattached to baby's clothing.

STEP 6 After sustained use and numerous recharging cycles, the recharge-able batteries may need to be replaced. Remove screw from Rechargeable Battery Compartment cover on back of Base Unit; remove cover.

(LD of batter screw/door being removed)

STEP 7 Remove Rechargeable battery and unclip power source wire as shown. Take battery to store with you to assure a correct battery selection when purchasing a replacement

(LD of Battery clip being separated)

STEP 8 Reattach new battery power source wire to Base unit power source clip as shown.

(LD of Battery clip being reattached)

STEP 9 Replace Rechargeable Battery Compartment Door and resecure screw.

(LD of batter screw/door being resecured)

Parent's Unit:

For best results, the Parent's Unit should be placed at least 10 feet away from the Baby's unit. The Parent's Unit can be mounted to the wall by using a screw (not included) to hang the unit using the keyhole on the belt clip on the back of the unit.

STEP 1 Select Channel to correspond to Channel on Baby's Unit.

STEP 2 Place the Parent's Unit at least 10 feet from the Baby's Unit.

STEP 3 Plug the adapter into an electrical outlet, then plug the round end of the adapter cord into the jack on the Parent's Unit. Turn the Unit on and set an appropriate volume level to hear baby at all times. The power-on LED Light on the Unit should be illuminated and solid green. Note: If using optional 4 AAA batteries (not included) for power, power-on LED will glow solid red when batteries need replacing.

STEP 4 For optional battery power, do not attach AC Adapter. Slide the Battery Door open in the direction of the arrow and insert 4 AAA batteries (not included). Ensure the (+) and (-) symbols match those shown in battery compartment as shown.

(LD of battery insertion)

Using Intercom Feature

STEP 1 To let baby hear your voice, press Talk Button and speak directly into the microphone.

STEP 2 Release Talk Button to hear bab's response or to monitor sounds

STEP 3 To lock out Talk Button from unsupervised use, slide button up as shown. This prevents anyone from talking to the baby unit.

Note: If you experience static or noise interference, switch both units to an alternate channel.

(LD of button operation for lock-out)

Note: If you experience a power failure, the Parent's Unit and the Baby's Unit will not automatically switch to battery power. You must disconnect the AC Adapters from the Parent's and the Baby's Unit. You must separate the Baby's Portable Monitor from the Base unit to use the rechargeable battery power and you must insert 4 AAA batteries (not included) into the Parent's unit for battery power.

LED SOUND LEVEL LIGHT INDICATORS/AUDIO-VISUAL ALARM INDICATORS

The five (5) RED LEDs at the top of the Parent's Unit light up to display the sound level coming from your baby. These sound level indicators are factory pre-set and are not affected by the volume setting. This feature allows you to view the relative volume level of your baby's sounds. It is most effective when you are in a noisy environment and may not be able to hear your baby's sounds clearly. The louder the sound, the more RED LEDs will light up.

These RED LEDs, along with the Speaker, also serve as a loss of signal alarm. When the Parent's unit is too far from the Baby's Unit for monitoring, the LEDs will flash and the Speaker will give off an audible alarm. Do Not use this feature as a "seek" function to locate your child.

Operating Tips

- Make sure that both units are on the same channel. Even though you may hear your baby's sounds, proper use of this system requires that both units must be on the same channel. If the units are on different channels, the signals from the Baby's Unit may be strong enough to be picked up by the Parent's Unit, but these signals are unreliable and may contain substantial static.
- When using the AC Adapters with household electricity, make sure the out-let has power. Some electrical outlets are powered through a wall switch in the room. If both Units are plugged in and "ON", the Power indicator LEDs

should be lit. If this does not take place, try placing the wall switch in the room in another position.

Troubleshooting Your Grow-With-Me Intercom Monitor

Problem	Possible cause	Solution
Warranty		

ONE (1) YEAR LIMITED WARRANTY Safety 1st... WARRANTY.

If you have questions or comments, please call our toll free Consumer Relations number. All Safety 1st products are guaranteed. If you are not completely satisfied, please return with proof of purchase to:

Safety 1st, Inc., 45 Dan Road, Canton, MA 02021 USA 800-723-3065

©1999 Safety 1st, Inc.

Safety 1st Canada, Inc., 804 rue Deslauriers, Ville St-Laurent, Quebec H4N1X1 Canada
800-721-3389

Safety 1st Europe, Ltd. Isopad House, Shenley Road, Borehamwood, Hertfordshire
WD61TE Great Britan +44(0) 20 8236 0707

10/99