

1. Photographs of Dynamic Frequency Selection Test Configuration

For AP Router mode (Master):

FRONT VIEW



CLOSE-UP VIEW




For Bridge mode (Slave without radar detection):

FRONT VIEW



CLOSE-UP VIEW



For Extender mode (Master):

FRONT VIEW



CLOSE-UP VIEW



For Mesh mode (Master):

FRONT VIEW



CLOSE-UP VIEW



————THE END————