






DUT Case Open (top) 3 Button and 4 Button Parts



DUT Case Open (bottom) 3 Button and 4 Button Parts



DUT PCB (top)



DUT PCB (bottom)