


BASE STATION

JAMES BOND

007™



1. Insert one 9 V battery in each device's battery compartment.
2. Turn the volume control to switch it on.
3. Speak into the integrated microphone while pressing the transmission button.
---- Release the button to listen.
4. Press the transmission button on the Base Station's microphone to talk
----(green light on). Release the microphone's button to listen (red light on).
5. To send Morse code signals, press the transmission button and the Morse code button; press and release the Morse button several times for the (.) or keep the button pressed slightly longer for (-).
6. You may practice Morse code with your transmitter by using the Morse code button only.
7. The greatest range is achieved in open spaces.

- ① VOLUME CONTROL, ON/OFF SWITCH
- ② FLEXIBLE ANTENNA
- ③ GREEN "TRANSMIT" LIGHT, RED "RECEIVE" LIGHT
- ④ MORSE CODE BUTTON
- ⑤ BUTTON PRESSED TO TRANSMIT
- ⑥ MICROPHONE

Do not mix used batteries with new ones. Do not mix alkaline batteries with regular or rechargeable ones. Do not use rechargeable batteries. Do not attempt to recharge non-rechargeable batteries. Remove the batteries from the device when not in use. Only use batteries of the same or equivalent type. Batteries must be inserted according to proper polarity. Battery replacement must be carried out by an adult.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

