

B1 ==> EMERGENCY RADIO ONLY
AND THE XTAL 4.19MHz MUST
CHANGE TO 4.032MHz CRYSTAL
N.U ==> NOT USE

*2. For CPU version HD704818 (OTP) Should connect the PAG PCB and disconnect the lead wire between "B" to channel key.

For CPU HD404818F97 verison
disconnet the PAG PCB and
connet the lead wire from
"B" to channel key.

