



WRIST TALKIES

WALKIE TALKIE SET

AGES 6 AND UP

Keep these instructions. DO NOT DISCARD.

- Requires 2 x 9V (6LR6) DC batteries.
- Only adults should install and replace batteries.
- Alkaline batteries are recommended for longer life.
- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Exhausted battery should be removed from toy.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel cadmium) batteries.
- Batteries must be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Only batteries of the same or equivalent type is recommended are to be used.

How to Use

1. Slip elastic hand strap over fingers and attach adjustable wrist strap comfortably around wrist.
2. Flip up antenna and click power-volume dial to ON. Turn dial to adjust volume.
3. Press talk-listen button to talk; light glows red. Speak into mike.
4. Release talk-listen button to listen; light glows green.
5. Click power-volume dial to OFF and flip antenna down over mike.

Battery


Each Wrist Talkie uses one 9 volt DC battery, not included. To install:

1. Remove screw and battery cover with a Phillips screwdriver.
2. Remove the used battery from the connector jack.
3. Plug a 9-volt alkaline battery onto the connector jack and fit it firmly into the battery compartment.
4. Replace the battery cover and the screw.



Care

Avoid Dropping, bumping or smashing them. Don't immerse them in water and avoid getting them wet.



Wrist Talkies
70013-4000-4L 2/99
Wild Planet Toys, Inc.

WARNING:

CHOKING HAZARD: Small Parts
Not for Children Under 3 Yrs.

**NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT.
SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.**