

FTT Reader

The FTT Reader is the electronic “brain” of the AXCESS NeuroTag™ RFID System. The Reader activates and reads NT132 Tags and outputs data in LonWorks protocol. Tag-reader communications platform enable advanced applications with capabilities such as Multi-Tag read and Read/Write. Data is transferred at the rate of 1K bits per second. The FTT reader is connected directly to a LonWorks network and can also be configured with add-on modules to facilitate stand alone operation and networking to other NT132 readers.

