

Label Location:



Figure 1: View of Label Location on EUT
Note: The “P6X” will be replaced with a P60 or P65



Figure 2: View of Label Location for Part Number and MAC ID inside the EUT Case for the OMNI-P65
Note: The Label location is identical for the OMNI-P60