

说明书
尺寸:150X78mm (展开尺寸:150X1092 mm)
128G, 双铜
风琴折, 双面印刷




Soundwave Mage

SOWO®


produkt bedienungsanleitung / mode d'emploi du produit / manuale di istruzioni del prodotto
manual de instrucciones del productot / руководство по эксплуатации изделия

1




3

2



4

3



5

NOTES:

- 2S Long press 2 seconds
- Green light is flashing
- Green light always on
- 1X Press once
- 2X Press 2 times
- Orange light is always on
- Orange light blinks

ANMERKUNGEN:

- 2S 2 Sekunden lang drücken
- Grünes Licht blinkt
- Grünes Licht leuchtet immer
- 1X Einmal drücken
- 2X 2 Mal drücken
- Oranges Licht leuchtet immer
- Oranges Licht blinkt

6

NOTES:

- 2S Appuyer longuement pendant 2 secondes
- La luce verde lampeggia
- La lumière verte est toujours allumée
- 1X Appuyer une fois
- 2X Appuyer 2 fois
- La lumière orange reste allumée
- La lumière orange clignote

NOTE:

- 2S Premere a lungo per 2 secondi
- La luce verde lampeggia
- Luce verde sempre accesa
- 1X Premere una volta
- 2X Premere 2 volte
- Luce arancione sempre accesa
- La luce arancione lampeggia

7

NOTAS:


- 2S Pulsación larga 2 segundos
- La luz verde parpadea
- Luz verde siempre encendida
- 1X Pulse una vez
- 2X Pulsar 2 veces
- Luz naranja siempre encendida
- La luz naranja parpadea

ПРИМЕЧАНИЯ:

- 2S Длительное нажатие в течение 2 секунд
- Зеленый свет мигает
- Зеленый свет горит постоянно
- 1X Нажмите один раз
- 2X Нажмите 2 раза
- Оранжевый индикатор горит постоянно
- Оранжевый свет мигает


8

4




9

5



10

6



11

12

13

14

Tech Specs

Bluetooth® Version:	V5.3
Transducer:	43mm/4Q
Frequency Response:	20Hz-20KHz
Signal-to-Noise Ratio:	> 84dB
Battery Type:	3.7V 1500mAh
Battery Charging Time:	2.5 hours
Music Playtime:	10 Hours/VERIES BY VOLUME LEVEL AND AUDIO CONTENT).
Wireless Transmission Distance:	Up to 39 ft (12M)
Charging:	DC 5 V 2A
Dimension(W x D x H):	120mm(L)*70mm(W)*45mm(T)
Weight:	200g
Waterproof Grade:	IP67

To extend battery life, fully charge at least once every 3 months. Battery life will vary according to usage patterns and environmental conditions. Do not expose the SOWO product to liquids without removing all cable connections and closing the cap tightly. Do not expose the SOWO product to water while charging. It may cause permanent damage to the speaker or product, and to the power source.

15

IMPORTANT SAFETY INSTRUCTIONS:

For all the products:

- Read and follow these instructions.
- Keep these instructions.
- Read all warnings.
- Follow all instructions.
- Do not block any ventilation openings. Install this product according to the instructions.
- Do not install this product near any heat sources such as radiators, heat recorders, or other heat generating devices (including amplifiers).
- Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong provided for your safety. If the plug does not fit into your outlet, consult an electrician to replace the outdated outlet.
- Protect the power cord from being stepped on or pinched, especially at plugs, receptacles and the point where they exit from the device.
- Use only attachments/accessories specified by the manufacturer.
- Unplug this device during lightning storms or when not used for long periods of time.
- To disconnect this device from the AC mains completely, disconnect the power supply cord plug into the AC receptacle.
- The mains plug of the power supply cord shall remain readily operable.
- Do not expose batteries to excessive heat such as sunlight fire or the like.
- This device is intended to be used only with the power supply and/or charging cable provided by the manufacturer.

17

FCC Requirement:

Any changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the device. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device shall not cause harmful interference.
 - (2) This device shall accept any interference received, including interference that may cause undesired operation.
- Note: This equipment has been tested and found to meet the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to attempt to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase separation between equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

18

Technische Daten

Bluetooth® Version	V5.3
Wandler:	43mm/4Q
Frequenzbereich:	80HZ-20KHZ
Signal-Rausch-Verhältnis:	> 84dB
Akkuart:	3.7V 1500mAh
Ladezeit:	2.5 Stunden
Musikwiedergabezeit:	10 Stunden (abhängig von der Lautstärke und dem Audio-Inhalt).
Bluetooth-Übertragungsentfernung:	Bis zu 12m (39 ft)
Aufladung:	DC 5 V 2A
Maße (B x T x H):	120mm(L)*70mm(W)*45mm(T)
Gewicht:	200g
Wasserdicht:	IP67

Um die Lebensdauer des Akkus zu verlängern, laden Sie ihn mindestens einmal alle 3 Monate vollständig auf. Die Lebensdauer der Batterie hängt von den Nutzungsmustern und den Umgebungsbedingungen ab.

Setzen Sie das SOWO-Produkt keinen Flüssigkeiten aus, ohne alle Kabelverbindungen zu entfernen und den Deckel fest zu verschließen. Setzen Sie das SOWO-Produkt während des Aufladens keinem Wasser aus. Dies kann zu dauerhaften Schäden am Lautsprecher oder Produkt und an der Stromquelle führen.

19