








Battery

RFMM Board
(Contains
Transceiver)

Connection to VCM



Shell – contains
RFMM Board
(Contains Transceiver)
Battery, and Super
Cap.

This cable delivers power to
VCM and Valve Motor

VCM board is inside
this plastic
horseshoe shaped
enclosure

Valve Motor and
Valve