

Label Location

The device can be delivered with a steel plate as is usually the case, then the label can be found on the bottom of the steel plate.



Label Location

If the device is delivered without the steel plate (for installation at a wall), the label is located on the bottom of the device.

