

FCC ID: NFY18301TX

HOW TO OPERATE:

- 1) INSTALL THE BATTERY IN TRANSMITTER FIRSTLY, THEN TURN ON THE SWITCH.
- 2) INSTALL THE BATTERY IN CHASSIS, THEN TURN ON THE SWITCH.
- 3) OPERATE THE VEHICLE WITH THE JOYSTICK.
- 4) AFTER TURN OFF THE VEHICLE.
- 5) TURN OFF THE TRANSMITTER
- 6) REMOVE ALL THE BATTERIES FROM THE VEHICLE AND THE TRANSMITTER.

BATTERY NOTE:

- 1) NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED
- 2) DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES ARE NOT BE MIXED.
- 3) ONLY BATTERIES OF THE SAME EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
- 4) BATTERIES ARE BE INSERTED WITH THE CORRECT POLARITY.
- 5) EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.
- 6) WHEN THE PLAY IS OVER, MUST REMOVE ALL THE BATTERIES. THE
- 7) SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.
- 8) RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED.
- 9) RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION.

CAUTION:

- 1) THE TOYS IS NOT INTENDED FOR CHILDREN UNDER 6 YEARS OLD.
- 2) BEFORE PLAY THIS TOYS, THESE INSTRUCTIONS BE NECESSARY FOR SAFE OPERATION OF THE TOYS.
- 3) THE PACKAGING HAS TO BE KEPT SINCE IT CONTAIN IMPORTANT INFORMATION.
- 4) PLEASE KEEP THIS BOX FOR THE FURTHER INFORMATION.

SAFETY RULES:

SELECT AS SAFE PLACE TO OPERATE YOUR VEHICLE. DO NOT DRIVE IN THE STREET. AVOID WATER OR DAMP LOCATION WHICH MAY DAMAGE THE VEHICLE'S ELECTRONICS. AVOID OPERATIONG AROUND BABY MONITORS, CORDLESS PHONES, ELECTRICAL APPLIANCES, ELECTRIC BASEBOARD HEATERS, HIGH VOLTAGE ELECTRICAL WIRES AND LARGE, STEEL-REINFORCED CONCRETE BUILDINGS ALL OF WHICH MAY CAUSE INTERFERENCE.


REMARK:

User cannot modify this product.

BATTERY REQUIREMENTS/INSTALLATION FOR TRANSMITTER & VEHICLE
PILAS E INSTALACION PARA MANDO TRANSMISOR Y VEHICULO

FCC ID: NFY18301TX

VEHICLE
VEHICULO



ON-OFF
ENCENDIDO-APAGADO

TRANSMITTER
MANDO TRANSMISOR

JOYSTICK
MANDOS

FORWARD

STOP

BACKWARD
WITH
REVERSE

ANTENNA
ANTENA

006P (9V) x1
6P (9V) x1

MADE IN CHINA
HECHO EN CHINA