




Pre check of worse-case position



Worse case Z axis (9kHz – 30MHz, Measurement Loop antenna angle: 0deg)