

FCC ID : NHZCTL-9800

The photographs title listing below is **FCC ID : NHZCTL-9800** 4" x 6"
photographs (each for one piece) :

- | | | |
|--------|-----|---------------------------|
| PHOTO. | 1. | EUT FRONT VIEW (CTL-9805) |
| PHOTO. | 2. | EUT FRONT VIEW |
| PHOTO. | 3. | EUT REAR VIEW |
| PHOTO. | 4. | EUT INSIDE VIEW |
| PHOTO. | 5. | EUT FRONT VIEW |
| PHOTO. | 6. | EUT REAR VIEW |
| PHOTO. | 7. | EUT COMPONENT SIDE VIEW |
| PHOTO. | 8. | EUT SOLDERING SIDE VIEW |
| PHOTO. | 9. | EUT SOLDERING SIDE VIEW |
| PHOTO. | 10. | EUT COMPONENT SIDE VIEW |
| PHOTO. | 11. | EUT SOLDERING SIDE VIEW |
| PHOTO. | 12. | EUT I/O PORT VIEW |
| PHOTO. | 13. | CPU FRONT VIEW |
| PHOTO. | 14. | CPU REAR VIEW |
| PHOTO. | 15. | RAM FRONT VIEW |
| PHOTO. | 16. | RAM REAR VIEW |
| PHOTO. | 17. | DVD ROM FRONT VIEW |
| PHOTO. | 18. | DVD ROM REAR VIEW |
| PHOTO. | 19. | POWER SUPPLY FRONT VIEW |
| PHOTO. | 20. | POWER SUPPLY REAR VIEW |
| PHOTO. | 21. | EUT FRONT VIEW (CTL-9800) |
| PHOTO. | 22. | EUT REAR VIEW (CTL-9800) |

PHOTO. 1. EUT FRONT VIEW



PHOTO. 2. EUT FRONT VIEW



PHOTO. 3. EUT REAR VIEW



PHOTO. 4. EUT INSIDE VIEW




PHOTO. 5. EUT FRONT VIEW




PHOTO. 6. EUT REAR VIEW



PHOTO. 7. EUT COMPONENT SIDE VIEW




PHOTO. 8. EUT SOLDERING SIDE VIEW




PHOTO. 9. EUT SOLDERING SIDE VIEW




PHOTO. 10. EUT COMPONENT SIDE VIEW




PHOTO. 11. EUT SOLDERING SIDE VIEW




PHOTO. 12. EUT I/O PORT VIEW




PHOTO. 13. CPU FRONT VIEW



PHOTO. 14. CPU REAR VIEW



PHOTO. 15. EUT VIEW




PHOTO. 16. EUT REAR VIEW




PHOTO. 17. EUT FRONT VIEW



PHOTO. 18. EUT REAR VIEW



PHOTO. 19. POWER SUPPLY FRONT VIEW




PHOTO. 20. POWER SUPPLY REAR VIEW



PHOTO. 21. EUT FRONT VIEW (CTL-9800)



PHOTO. 22. EUT REAR VIEW

