

SAFETY INFORMATION FOR SL-2000

Your device contains a low power transmitter. When device is transmitted it sends out radio frequency (RF) signals. This device is authorized to operate at a duty factor not to exceed 30%.

CAUTION: To maintain compliance with the FCC's RF exposure guidelines,

this equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Use only the supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.