

Product Description

Tire Pressure Monitoring System is used for monitoring and indicating information of air pressure in vehicle's tires.

Transmitter sends receiver the data that are information of air pressure in vehicle's tire through ANT.

The data also include temperature, battery voltage and identity code of transmitter.

The receiver judges the data.

If the data of air pressure and others are not normal condition, the receiver sends a signal to a warning lamp.

Then, the warning lamp warns drivers.

NOTE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.