


Fig. 8.5 Motherboard Intel Redwood (BA2398) - Components side






Fig. 8.3 Internal left side view with metal panel removed





Fig. 8.11 IF 2093 interconnection board - Components side

Fig. 8.12 IF 2093 interconnection board - Foil side






Fig. 8.7 IF 2079 SAF-TE board - Components side




Fig. 8.8 IF 2079 SAF-TE board - Foil side




Fig. 8.14 Power Supply Unit MAGNETEK model 3783-45-2. Components Side




Fig. 8.15 Power Supply Unit MAGNETEK model 3783-45-2. Foil Side




Fig. 8.2 Overall rear view




Fig. 8.10 IF 2067 interconnection board - Foil side




Fig. 8.9 IF 2067 interconnection board - Components side




Fig. 8.6 Motherboard Intel Redwood (BA2398) - Foil side