



1. External Photograph of EUT

Model Name: PD29150





**Model Name: PD29150**





Model Name: PD29150

**Sample 2**





**Model Name: PD29150**



**2. Photograph of Accessory****Model Name: PD29150****List of Accessory:**

| Specification of Accessory |            |             |
|----------------------------|------------|-------------|
| AC Adapter 1               | Brand Name | Emerson     |
|                            | Model Name | TC U250     |
| AC Adapter 2               | Brand Name | Delta       |
|                            | Model Name | TC U250     |
| Battery 1                  | Brand Name | HT          |
|                            | Model Name | BD29100     |
| Battery 2                  | Brand Name | TWS         |
|                            | Model Name | BD29100     |
| USB Cable 1                | Brand Name | Coxoc       |
|                            | Model Name | DC M410     |
| USB Cable 2                | Brand Name | Foxlink     |
|                            | Model Name | DC M410     |
| Earphone 1                 | Brand Name | Cotron      |
|                            | Model Name | HS G400     |
| Earphone 2                 | Brand Name | Merry       |
|                            | Model Name | HS G400     |
| Camera 1                   | Brand Name | Liteon      |
|                            | Model Name | 09P1BA503   |
| Camera 2                   | Brand Name | PRIMAX      |
|                            | Model Name | NBRB76      |
| LCM-Main                   | Brand Name | Sharp       |
|                            | Model Name | LQ043Y1DX02 |
| LCM-2nd                    | Brand Name | AUO         |
|                            | Model Name | H430VL02 V4 |

**Remark:** For accessories equipped with this EUT, please refer to the following photos.



Model Name: PD29150



Model Name: PD29150

**Battery 1**

Model Name: PD29150

Battery 2



Model Name: PD29150

AC Adapter 1



Model Name: PD29150

**AC Adapter 2**