
>>> 1.4 System Requirements


Before installing the PC54G (MS-6825), your PC should meet the following:



- Desktop PC with standard PCI slot.



- Windows® 98SE/ME/2000/XP operating system.



- Minimum 5MB free disk space for installing the driver and utilities.



- CD-ROM drive, double speed or higher.

>>> 1.5 Package Contents

Unpack the package and check all the items carefully. If any item contained is damaged or missing, please contact your local dealer as soon as possible. Also, keep the box and packing materials in case you need to ship the unit in the future. The package should contain the following items:



- One Wireless 11g PCI Card.

- One external antenna.



- One Quick Installation Guide.



- One CD title including drivers, utilities, user's manual and quick guide.

>>> 1.6 Product View

Antenna Connector - connecting the external antenna.



External Antenna

Golden Finger

ACT LED - GREEN, indicating the networking status by:

- ON - The PC54G (MS-6825) is connected.
- Flash - The PC54G (MS-6825) is searching for available Access Point or receiving/transmitting data over the wireless network.