

NVI-KAM9230-K5 Labeling

Label information (OS Linux)

The label is centrally arranged on the rear side of the device.



Label information (OS WINCE)

The label is centrally arranged on the rear side of the device.

