

**SHARPER
IMAGE®**

Bluetooth Sound Bar

User Guide

SBT2010

In the box



Side panel

1 Standby Input

2 Line in

3 Vol+

4 Vol-

5 DC 18V

- 
- The image shows the front cover of a user guide for a Sharp Image Bluetooth Sound Bar. The cover has a dark grey background. At the top left, the words "SHARP" and "IMAGE" are stacked vertically in a large, white, sans-serif font. Below this, a horizontal light blue band contains the text "Bluetooth Sound Bar" in a smaller, white, sans-serif font. In the center of the cover is a black, elongated, wedge-shaped sound bar. At the bottom, the words "User Guide" are printed in a large, white, sans-serif font, and below that, the model number "SBT2018" is printed in a smaller, white, sans-serif font.

1 RCA to 3.5mm Cable

-

-
- Diagram of a car stereo control panel with numbered callouts 6 through 12:
- 6: STANDBY button (red square)
 - 7: LINE IN button
 - 8: RESET button
 - 9: MUTE button
 - 10: BASS button
 - 11: TREBLE button
 - 12: EQ button

-


Diagram illustrating the proximity requirement: A tablet and a smartphone are shown on the left, connected by a double-headed arrow labeled "within 3 feet" to a speaker on the right.

The diagram illustrates a Bluetooth connection setup. On the left, a smartphone is shown with a line pointing to a Bluetooth settings menu on its screen. The menu includes a toggle switch for 'Bluetooth' which is turned 'ON'. Below this, under the heading 'Devices', there is a list containing 'SBT2010' with a 'Paired' status next to it. A line also connects the smartphone to the 'SBT2010' device, indicating the connection path.

The diagram shows a mobile phone with a screen displaying the Bluetooth settings. The 'Discoverable' option is highlighted with a callout line pointing to the phone's screen.

- Go to **SETTINGS > BLUETOOTH > MENU > Search for devices** (Make sure Bluetooth is turned ON)

Review the instruction manual that came with your phone/device.



-

Rese

Equalizer

Play/Pause

Adjusting the volume



- **CAUTION**
RISK OF ELECTRIC SHOCK
DO NOT OPEN
- **ATTENTION**
RISQUE D'ÉLECTROCUTION
NE PAS OUVRIR
- **CAUTION**
RISK OF ELECTRIC SHOCK
DO NOT OPEN
- **ATTENTION**
RISQUE D'ÉLECTROCUTION
NE PAS OUVRIR

- ☎ Phone: 1-877-768-8481
Monday-Friday 8AM-10PM(EST)



● THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTEE OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

- ## SHARPER IMAGE