



倒退时转弯



11. when vehicle moves backward, turn the steering wheel counter-clockwise (fig.15), vehicle will turn inward left.
12. when vehicle moves backward, turn the steering wheel clockwise (fig.15), vehicle will turn inward right.

PROPER USE AND PRECAUTIONS




Store vehicle in cool dry place and away from direct heat sources.



Never drive in a rainy weather.



Avoid sand, mud and salt.



Do not leave vehicle in direct sunlight for long periods as damage may occur.



Avoid collisions with hard surface.




Never drive on grass.

16

COMPONENT CHECK LIST

PLEASE SEARCH THE TRAY AND REMOVE ALL OF THE COMPONENTS LISTED BELOW.



BATTERY PACK INSTALLATION IN VEHICLE AND TRANSMITTER

