


Directory

Welcome to TOUCH-BOLT System.....	
Introduction.....	
System Requirement.....	
Minimum Requirement.....	
Recommended Specification.....	
Supported input/output Device.....	
Start and Close the Application.....	
User Guide.....	
Project Management.....	
Construction Key.....	
Create a Programming Key.....	


Project Management



The screenshot displays a software window titled "Project Management System". Inside, there are tabs for "Project Management", "Construction Key", and "Programming Key". Below the tabs is a toolbar with four icons: a plus sign for "Add", a pencil for "Edit", a trash can for "Delete", and a document with a magnifying glass for "Report". The main area contains a table with four columns: an empty header cell, "Customer Name", "Project Name", and "Project Code". The first data row is highlighted in blue and contains "TFH", "TFH R&D", and "72662432". The second data row contains "ABC", "ABC-1", and "07842582".

	Customer Name	Project Name	Project Code
▶	TFH	TFH R&D	72662432
	ABC	ABC-1	07842582

Project Management




The screenshot shows a web application window titled "Edit Project". It contains a form with the following fields and values:

- Customer Name:** DEF
- Project Name:** DEF-1
- Invoice:** (empty)
- Contact:** (empty)
- TEL:** 1234567
- Address:** 88 TF
- Project Code:** 25178469

Below these fields is a large text area containing a long alphanumeric string: Oo5+e9RFZuqe+CaVHGOSLU3yZKhAFaUDzy1mxjaHMeY=.

Please refer to the user guide for more details.

Project Management



The screenshot displays a software window titled "Project Management System". Inside, there are tabs for "Project Management", "Construction Key", and "Programming Key". Below the tabs is a toolbar with four buttons: "Add" (with a plus icon), "Edit" (with a pencil icon), "Delete" (with a trash icon), and "Report" (with a printer icon). The main area contains a table with three columns: "Customer Name", "Project Name", and "Project Code". The first row of the table is highlighted in blue and contains the values "TFH", "TFH R&D", and "72662432". The second row contains "ABC", "ABC-1", and "07842582". The third row contains "DEF", "DEF-1", and "25178469".

	Customer Name	Project Name	Project Code
▶	TFH	TFH R&D	72662432
	ABC	ABC-1	07842582
	DEF	DEF-1	25178469

Construction Key

Project Management System

Project Management Construction Key Programming Key

Create Key

UID

1297461883 R

The key is assigned to project:

ABC-1
DEF-1
TFH R&D
2010/09/14

Ending date

2015/09/14

Search

Customer name: Project name: 🔍

Customer Name	Project Name	Project Code	UID
TFH	TFH R&D	72662432	1297462907

Please refer to the user guide for more details.

Construction Key




Table of Content


Welcome to Touch-Bolt Centra.....	
Introduction.....	
System Requirement.....	
Minimum Requirement.....	
Recommended Specification.....	
Supported input/output Device.....	
Start and Close the Application.....	
User Guide.....	
Home	
Floor Plan	
Propentty management	
Public Area	
Public Area Group	
Public Area Locks	
General Area	
Zone	

Suite	
Unit	
Calendar and Timetable settings	
Time Table	
Holiday	
DST	
Operation	
Resident management	
Staff management	
Vendor management	
Vendor	
Employee	
Work order type	
Keys	
Create Key	
Resident Key	
Zone Key	
Master Key	
Temporary Key	

Latch On/Off Key	
Emergency Key	
Duplicate Key	
Black List	
Read Key	
Locks	
Lock Setting	
RetrieveLock information	
Reports	
Key History	
Lock History	
Lock Events	
Activity logs	
System Settings	
System Account Management	
Account Type Settings	
IM-1000&dongle Setup	
Database	


Home

Floor Plan




Please refer to the user guide for more details.

Floor Plan > Property management



05 Please refer to the user guide for more details.

Floor Plan > Property management



The screenshot shows a 'Property management' dialog box with a 'General' tab selected. The dialog has a title bar with a standard Windows icon and the text 'Property management'. On the left side, there is a vertical toolbar with a checkmark icon and the text 'OK'. The main area contains four labeled text input fields: 'Property Name' with the value 'TFH R&D', 'Property code' with the value '72662432', 'Address' which is empty, and 'Registry Key' with the value 'tJuZk3L4KxPnlq+cbtP6fOlSdQ84jNeSJdnB33v5FAr5tIC5LuORA=='. The 'Registry Key' field is the largest and has a light blue border.

Property management

OK

General

Property Name: TFH R&D


Property code: 72662432

Address:

Registry Key: tJuZk3L4KxPnlq+cbtP6fOlSdQ84jNeSJdnB33v5FAr5tIC5LuORA==

Please refer to the user guide for more details.

Floor Plan > Public Area > Public Area Group



Floor Plan > Public Area > Public Area Locks


The screenshot shows a software interface for managing public areas. It is divided into two main sections: 'Public Area Group' on the left and 'Public Area Locks' on the right. Both sections have a toolbar with 'Add', 'Edit', and 'Delete' icons. The 'Public Area Group' table lists 'Pool' and 'Garage'. The 'Public Area Locks' table lists 'P. Front' and 'P. Back'.

	Name
1	Pool
2	Garage


	Name
1	P. Front
2	P. Back

Please refer to the user guide for more details.

Floor Plan > Public Area > Public Area Locks



Floor Plan > Public Area > General Area



Please refer to the user guide for more details. 10

Floor Plan > Public Area > Zone / Suite / Unit


The screenshot shows a software window titled "General Area" with three main sections: Zone, Suite, and Unit. Each section has a toolbar with "Add", "Edit", and "Delete" icons. Below each toolbar is a table.

Zone		
	Zone Name	Lock
▶	1	
	RD	

Suite	
	Suite Name
▶	1

Unit	
	Unit Name
▶	1

Floor Plan > Calendar and Timetable Settings



Please refer to the user guide for more details.

Floor Plan > Calendar and Timetable Settings > Time Table

Calendar and Timetable settings

Time Table | Holiday | DST

+ Add Edit Delete

Group

TimeTable Name
Weekday 0000-1700
Weekend ALL
T1
T2
T3

Time

✓ Set ✗ Erase

	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Mon																								
Tue																								
Wed																								
Thu																								
Fri																								
Sat																								
Sun																								
Holiday																								

Floor Plan > Calendar and Timetable Settings > Holiday

Calendar and Timetable settings

Time Table Holiday DST

Holiday Name Holiday Date 2015/ 9/14 

	Name	Holiday Date	Delete
▶	9/15 test holiday	2015/9/15	
	New Year	2015/9/14	

Please refer to the user guide for more details.

Floor Plan > Calendar and Timetable Settings > DST

Calendar and Timetable settings

Time Table Holiday DST

OK

DST Type
LOCAL STANDARD

☐ Remind DST

DST Start

Month
September

Occurs
2nd

Day of the Week
Fri

Hour Of Day(1-22)
0

Time adjustment
0

2015/ 9/11

DST End

Month
September


Occurs
2nd

Day of the Week
Fri

Hour Of Day(1-22)
0

2015/ 9/11

Operation



Please refer to the user guide for more details. 16

Operation > Resident management

The screenshot displays the 'Resident management' application window. It features a toolbar with 'Add', 'Edit', 'Delete', and 'Resident Key' buttons. A table lists residents, with the first entry 'Iris Wu' selected. An 'Edit Resident' dialog box is open, showing the details for 'Iris Wu'.


Full name	Work Phone	Home Phone
Iris Wu	1234556	09111111

First Name	Middle Name	Last Name
Iris		Wu

Home Phone No.	Work Phone No.
09111111	1234556


Notes:
sehrhjtggf

Operation > Staff management




Please refer to the user guide for more details.

Operation > Vendor manggement > Vendor



Operation > Vendor manggement > Employee



Please refer to the user guide for more details.

Operation > Vendor manggement > Work order type

The screenshot displays two windows from a software application. The background window, titled 'Work order type', features a menu bar with 'Add', 'Edit', 'Delete', and 'Report'. Below the menu is a 'Search Condition' section with a 'Work Order Type' dropdown (set to 'Unit'), radio buttons for 'Unit' (selected) and 'Property', and checkboxes for 'Pending', 'Open', and 'Close'. Search and Reset buttons are also present. The main area shows a table with columns: rowid, Work Order No., Unit/Property, Status, and Assigned To. The foreground window, titled 'Add Work order', has an 'OK' button and contains the following fields: 'Work Order Number' (201509150002), 'Work Order Type' (Unit), 'Priority' (dropdown), 'Status' (dropdown), 'Requested By' (text field with a 'Load' button), 'Assigned To' (text field with a 'Load' button), 'Job Description' (text area), and 'Special Circumstances' (text area).

Operation > Vendor manggement > Work order type

Add Work order

✓ OK

Work Order Number
201509150002

Work Order Type
☒ Unit ☐ Property
A10001

Priority
High
Normal
Low

Requested By
...

Assigned To
...

Job Description

Please refer to the user guide for more details.

Operation > Vendor manggement > Work order type

Add Work order

OK

Work Order Number
201509150002

Work Order Type
☒ Unit ☐ Property
A10001

Priority
[Dropdown]

Status
Pending
Open
Closed

Requested By
[Text Field] [Selection Button]

Job Description
[Text Field] [Selection Button]

Operation > Vendor manggement > Work order type

The image shows two overlapping windows from a software application. The background window is titled 'Add Work order' and contains the following fields:

- Work Order Number:** 201509150002
- Work Order Type:** Unit (selected), Property
- Priority:** (dropdown menu)
- Status:** (dropdown menu)
- Requested By:** (text field)
- Assigned To:** (text field)
- Job Description:** (text area)
- Special Circumstances:** (text area)

The foreground window is titled 'Select user' and contains the following fields:

- User Type:** STAFF (selected), RESIDENT, VENDOR
- User List:** A table with two rows: 'J L' and 'Iriss Wu'.

Name
J L
Iriss Wu

Operation > Vendor manggement > Work order type

The screenshot shows a software interface for adding a work order. The main dialog, titled 'Add Work order', contains the following fields and controls:


- Work Order Number:** A text field containing '201509150002'.
- Work Order Type:** A dropdown menu with 'Unit' selected. Below it, radio buttons for 'Unit' (selected) and 'Property' are visible.
- Priority:** A dropdown menu.
- Status:** A dropdown menu.
- Requested By:** A text field with a small 'OK' button next to it.
- Assigned To:** A text field with a small 'OK' button next to it.
- Job Description:** A large text area.
- Special Circumstances:** A large text area.

A secondary dialog, titled 'Select user', is overlaid on the main dialog. It contains:

- User Type:** Radio buttons for 'STAFF' (selected), 'RESIDENT', and 'VENDOR'.
- User List:** A table with two columns: 'Name' and a selection column.


Name	
J L	☒
Iriss Wu	☐

Keys




Please refer to the user guide for more details.

Keys > Create Key > Resident Key / Zone Key / Master Key /
Temporary Key / Latch on/off Key / Emergency Key




Keys > Duplicate Key / Black List / Read Key




Please refer to the user guide for more details.

Locks > Lock Setting / Retrieve Lock information




Reports > Key History / Lock History / Lock Events / Activity Logs




Please refer to the user guide for more details.

System Settings




System Settings > System Account Management




Please refer to the user guide for more details.

System Settings > Account Type Settings




System Settings > Account Type Settings




Please refer to the user guide for more details.

System Settings > Account Type Settings




System Settings > IM-1000&dongle Setup



Please refer to the user guide for more details.

System Settings > Database



DECLARATIONS AND SAFETY STATEMENTS

FEDERAL COMMUNICATIONS COMMISSION STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

IC REGULATIONS

RÈGLEMENTS D'IC

This device complies with Industry Canada licence-exempt RSS-210, RSS-247 standard. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.