

4.1

ACCESSORIES:

QUICK GUIDE / USER MANUAL



QUICK GUIDE



USER MANUAL

Thank you for purchasing this innovative LOGIC device. The specifications in this document are subject to change without prior notice.

LOGIC and the LOGIC logo are registered trademarks of Swagtek, Inc. Other trademarks are the property of their respective owners.

Charge for 24 hours before using.

Get to know your Logic phone

Install SIM card / memory card.

Connect your Logic phone to the computer using a USB cable (not included).

Copy music files from your computer to your Logic phone.

Thank you for purchasing this innovative LOGIC device. The specifications in this document are subject to change without prior notice.

LOGIC and the LOGIC logo are registered trademarks of Swagtek, Inc. Other trademarks are the property of their respective owners.

Instalar tarjeta SIM / tarjeta de memoria.

Conecte su teléfono Logic a una computadora utilizando un cable USB (no incluido).

Transfiera sus archivos de música desde su computadora a su teléfono Logic.

Thank you for purchasing this innovative LOGIC device. The specifications in this document are subject to change without prior notice.

LOGIC and the LOGIC logo are registered trademarks of Swagtek, Inc. Other trademarks are the property of their respective owners.

Instalar tarjeta SIM / tarjeta de memoria.

Conecte su teléfono Logic a una computadora utilizando un cable USB (no incluido).

Transfiera sus archivos de música desde su computadora a su teléfono Logic.

6

5

4

3

2

1

SHEET - FRONT SIDE
OPEN SIZE WITH BLEED: 100.33mm X 405.892mm

CLOSE FINISHED SIZE: 67.31mm X 95.758mm

SHEET - BACK SIDE
OPEN SIZE WITH BLEED: 100.33mm X 405.892mm

CLOSE FINISHED SIZE: 67.31mm X 95.758mm

