

Operation Description

Hardware Installation

1.Connecting the receiver module

For USB Interface

- Plug the receiver cable into the USB port of your system.
- System will automatically detect for new hardware.
- Follow system instruction for setup



For USB and PS/2 Combo (If no USB port)

- Connect the PS/2 adaptor to the USB connector of the receiver.
- Restart your system.

